




Stack Visualisations



Stack visualisations are designed to provide information regarding the stack pointer and stack type for the stack access instructions `LDM[type]` and `STM[type]`. The visualisation can be viewed by using the button `Show Stack` that automatically appears when needed, or by using the keyboard shortcut `Shortcut+Alt+K` if the visualisation has been disabled via the [settings panel](#).

`Shortcut` is `Ctrl` for Windows and Linux, and `Cmd` for Mac OS X.

The following information is provided in the stack visualisations:

Item	Description
Pointer name	The register name <code>R0-R14</code> used as the stack pointer
Base address	The value of the stack pointer at the start of execution
Access mode	<code>Load</code> for <code>LDM</code> instructions, and <code>Store</code> for <code>STM</code> instructions
Stack type	One of the 4 overarching stack types: <code>Fully Descending</code> , <code>Fully Ascending</code> , <code>Empty Descending</code> , <code>Empty Ascending</code>
Behaviour	A one-line summary of the stack behaviour
Write-back disabled	The stack pointer remains unchanged after execution
Write-back enabled	After execution, the stack pointer is updated to the <code>Pointer After</code> value as shown
Stack table	Shows registers, memory addresses and values in memory part of the stack