EEEN313/ECEN405 Power (Electric)

CAPITAL THINKING.
GLOBALLY MINDED.
MAI I TE IHO KI TE PAE




1

Sine and Cosine

• Alternating Current (AC) — Sines and Cosines that move large blocks of energy from one place to another


Cosine starts at t=0 The period of cosine is τ We say that this is a *leading* phase angle ϑ .



CAPITAL THINKING. GLOBALLY MINDED. MAI I TE IHO KI TE PAE



AC Power




• We can treat AC power as a function of time (in sine and cosine)

$$v(t) = V_{peak} \cos(2\pi f t + \theta_v)$$

$$i(t) = I_{peak} \cos(2\pi f t + \theta_i)$$

$$p(t) = v(t)i(t)$$



P(t) is instantaneous power

But this isn't very useful, because we really need to know how much power is being delivered on the average.

More important, how much energy is being moved (this is what power companies want us to pay for)

CAPITAL THINKING. GLOBALLY MINDED.




3

Instantaneous Power

Instantaneous Power – power at instant in time

$$p(t) = v(t) \ i(t)$$

- If p(t) has positive value (current in same direction as positive voltage polarity) it is source of power
- if negative then it is sink (dissipater) of power





Energy

- is the time integral of power
 - often use symbol W (but units are joules)
 - (do not confuse with unit for power Watts, W)


$$W = \int_{t_1}^{t_2} p(t) dt$$

CAPITAL THINKING. GLOBALLY MINDED.



5

Average Power



- Power Averaged over entire cycle
- Also known as real power or active power

$$P_{av} = \frac{1}{T} \int_{0}^{T} p(t)dt = \frac{1}{T} \int_{0}^{T} v(t)i(t)dt = \frac{W}{T}$$


CAPITAL THINKING. GLOBALLY MINDED.



6

Example


- Find:
 - The instantaneous power
 - Energy absorbed by the device in one period
 - Average power absorbed by the device



CAPITAL THINKING. GLOBALLY MINDED.



7




$$v(t) = \begin{cases} 20 \text{ V} & 0 < t < 10 \text{ ms} \\ 0 \text{ V} & 10 \text{ ms} < t < 20 \text{ ms} \end{cases}$$


$$i(t) = \begin{cases} 20 \text{ A} & 0 < t < 6 \text{ ms} \\ -15 \text{ A} & 6 \text{ ms} < t < 20 \text{ ms} \end{cases}$$

(a) Instantaneous power is simply:

$$p(t) = \begin{cases} 400 \text{ W} & 0 < t < 6 \text{ ms} \\ -300 \text{ W} & 6 \text{ ms} < t < 10 \text{ ms} \\ 0 & 10 \text{ ms} < t < 20 \text{ ms} \end{cases}$$



$$p(t) = \begin{cases} 400 \text{ W} & 0 < t < 6 \text{ ms} \\ -300 \text{ W} & 6 \text{ ms} < t < 10 \text{ ms} \\ 0 & 10 \text{ ms} < t < 20 \text{ ms} \end{cases}$$



CAPITAL THINKING.
GLOBALLY MINDED.
MAI I TE IHO KI TE PAE

VICTORIA UNIVERSITY OF WELLINGTON TE HERENGA WAKA

9

(a) Instantaneous power is simply:

$$p(t) = \begin{cases} 400 \text{ W} & 0 < t < 6 \text{ ms} \\ -300 \text{ W} & 6 \text{ ms} < t < 10 \text{ ms} \\ 0 & 10 \text{ ms} < t < 20 \text{ ms} \end{cases}$$

(b) Energy absorbed by the device in one period is:

$$W = \int_{0}^{T} p(t)dt$$

$$= \int_{0}^{0.006} 400dt + \int_{0.006}^{0.010} (-300)dt + \int_{0.010}^{0.020} (0)dt$$

$$= 2.4 - 1.2 = 1.2 \text{ J}$$



(a) Instantaneous power is simply:

$$p(t) = \begin{cases} 400 \text{ W} & 0 < t < 6 \text{ ms} \\ -300 \text{ W} & 6 \text{ ms} < t < 10 \text{ ms} \\ 0 & 10 \text{ ms} < t < 20 \text{ ms} \end{cases}$$

(c) Average power is

$$P_{av} = \frac{1}{T} \int_{0}^{T} p(t)dt$$

$$= \frac{1}{0.020} \left[\int_{0}^{0.006} 400dt + \int_{0.006}^{0.010} (-300)dt + \int_{0.010}^{0.020} (0)dt \right]$$

$$= 60 \text{ W} \qquad \left(= \frac{W}{T} \right)$$

CAPITAL THINKING. GLOBALLY MINDED. MAI I TE IHO KI TE PAE



11

DC Source

• DC voltage with average current

$$P_{dc} = \frac{1}{T} \int_{t_0}^{t_0+T} v(t)i(t) dt = \frac{1}{T} \int_{t_0}^{t_0+T} V_{dc} i(t) dt$$

• If the circuit is purely resistive v=Ri

$$P_{av} = \frac{R}{T} \int_0^T i^2(t) dt$$



RMS – Root Mean Square

• For the rms current I

$$P_{av} = RI_{RMS}^2$$

Hence the term 'RMS'


$$P_{av} = \frac{R}{T} \int_0^T i^2(t) dt \qquad I_{RMS} = \sqrt{\frac{1}{T} \int_0^T i^2(t) dt}$$

CAPITAL THINKING. GLOBALLY MINDED.



13

AC Power Quantities - Averages



 Average power comes from averaging the instantaneous power p(t) over one period of the ac waveform

$$p(t) = \left[V_{peak} \cos(2\pi f t + \theta_v) \right] \left[I_{peak} \cos(2\pi f t + \theta_i) \right]$$

$$P_{av} = \frac{V_{peak} I_{peak}}{2} \cos(\theta_v - \theta_i) \quad \text{Good for Mathematicians}$$

$$p(t) = \frac{V_{peak} I_{peak}}{2} \left[\cos(\theta_v - \theta_i) + \cos\left(4\pi f t + (\theta_v - \theta_i)\right) \right]$$

We don't use the peak values in AC systems; we use RMS value. For sine wave $V_{peak}/\sqrt{2}$ = $0.707~V_{peak}$

$$P = V_{RMS} I_{RMS} \cos(\theta_{v} - \theta_{i})$$



RMS from Peak Values

Rectangular pulse (duty cycle D)	$V_{\rm RMS} = V_{p} \sqrt{D}$
Sinusoids	$V_{RMS} = V_p / \sqrt{2}$
Full-wave rectified sinusoids	$V_{RMS} = V_p / \sqrt{2}$
Half-wave rectified sinusoids	$V_{RMS} = V_p/2$
Sum of different frequency sinusoids	$V_{RMS} = \sqrt{V_{1,RMS}^2 + V_{2,RMS}^2 + \dots}$
Triangular wave	$V_{\rm\scriptscriptstyle RMS} = V_{\scriptscriptstyle p} / \sqrt{3}$

(substitute *I* for *V* to determine currents)

CAPITAL THINKING. GLOBALLY MINDED.



15

Sum of periodic waveforms

• If periodic voltage is the sum of two periodic voltage waveforms $v_1(t) + v_2(t)$

$$V_{RMS}^{2} = \frac{1}{T} \int_{0}^{T} (v_{1} + v_{2})^{2} dt$$

$$= \frac{1}{T} \int_{0}^{T} v_{1}^{2} dt \frac{1}{T} \int_{0}^{T} 2v_{1}v_{2} dt + \frac{1}{T} \int_{0}^{T} v_{2}^{2} dt$$

• If the voltages are of two different frequencies (orthogonal), then the term v_1v_2 is zero

CAPITAL THINKING.
GLOBALLY MINDED.
MAI I TE IHO KI TE PAE



Clicker Quiz

The rms voltage of a rectangular wave is dependent on duty cycle D.

- A. True
- B. False

CAPITAL THINKING. GLOBALLY MINDED.



17

Clicker Quiz

The Average Power and Energy are related by time only

- True
- False



