Cheat sheet



FlightMode	Switch	Position
Position (Angle mode)		
Altitude (GNSS support off)		
Stabilized (Manual)		
Rattitude		
Acro		
Mission		
RTH		

Power on/off

Power on: Hold power button on drone for 8sec until LEDs are on.

The Speed Slider must be set to "Rabbit"!

Power off: Remove battery

Motor Start / Stop

Hold throttle stick in the lower right corner

Flying

- ✔ Check location (rules and regulations)
- ✔ Free space for GPS signals, no potential reflectors to avoid multi-path reception
- ✔ Drone battery full, ST16 battery full
- Check battery voltage during flight

Bind mode: nsh shell command "typhoon_bind start"