
MP3/MP4 Media Player
User
Manage Media Files
Control Playback
Navigate Playlist
Manage Audio
Configure Playback Modes
Control Full Screen