

DAY 4

1. **Connect a USB webcam to your computer, install any required drivers, and verify that the webcam works by opening the default camera app and capturing a photo.**

Step 1: Turn on the Computer

Turn on the computer and wait until Windows starts completely. Log in to your user account.

Step 2: Connect the USB Webcam

Insert the USB cable of the webcam into an available USB port on the computer. Make sure the connection is secure.

Step 3: Wait for Windows to Detect the Webcam

Windows will automatically detect the webcam. Wait until you see a message such as "Setting up device" or "Your device is ready to use."

Step 4: Install the Required Drivers

If Windows installs the drivers automatically, wait until the installation is complete. If not, install the drivers using the driver CD or download them from the manufacturer's official website. Restart the computer if required.

Step 5: Open the Camera App

Click the Start menu, type Camera, and open the Camera application. If prompted, allow the app to access the webcam.

Step 6: Capture a Photo

When the live camera preview appears, position the webcam correctly and click the Capture (camera) button to take a photo.

Step 7: Verify the Webcam is Working

Check that the captured photo has been saved successfully in the Pictures > Camera Roll folder. If the photo is clear and the Camera app displayed a live preview before taking the picture, it confirms that the webcam is connected properly, the drivers are installed correctly, and the webcam is working successfully.

2. **Set up a local printer (USB or network), install the correct driver, and print a test page to confirm successful installation.**

Step 1: Turn on the Computer and Printer

Turn on your computer and the printer. Ensure that the printer is ready for setup and has paper loaded in the paper tray.

Step 2: Connect the Printer

- **For a USB Printer:** Connect the printer to the computer using a USB cable and switch on the printer.
- **For a Network Printer:** Connect the printer to the same Wi-Fi network as the computer by following the printer's wireless setup instructions.

Step 3: Install the Printer Driver

Windows usually detects the printer automatically and installs the required driver. If the driver is not installed automatically:

- Insert the driver CD that came with the printer and follow the installation instructions.
- Or download the latest driver from the printer manufacturer's official website and install it.
- Restart the computer if prompted.

Step 4: Add the Printer

Open **Settings > Bluetooth & devices > Printers & scanners** and click **Add device**. Windows will search for available printers. Select your printer from the list and click **Add device** to complete the installation.

Step 5: Verify the Printer Installation

Go to **Settings > Bluetooth & devices > Printers & scanners** and confirm that the printer appears in the list of installed printers. If it is listed without any error messages, the installation was successful.

Step 6: Print a Test Page

Select the installed printer, click **Printer properties**, and then click **Print Test Page**. Wait for the printer to print the test page.

Step 7: Confirm Successful Installation

Check the printed test page. If the page prints correctly with clear text and graphics, it confirms that the printer has been installed successfully, the correct driver is working, and the printer is ready for use.

3. Simulate a connectivity issue by unplugging the printer's USB cable, then use Windows Device Manager to identify and resolve the 'printer not detected' problem. Hint: Check for error icons and use the 'Scan for hardware changes' option after reconnecting.

>>>

Step 1: Connect and Verify the Printer

First, connect the printer to the computer using the USB cable and turn on both the computer and the printer. Ensure that the printer is working properly before starting the task.

Step 2: Simulate the Connectivity Issue

Unplug the printer's USB cable from the computer. After disconnecting the cable, Windows will no longer detect the printer, and the printer may appear as Offline or Not Detected.

Step 3: Open Windows Device Manager

Press Windows + X on the keyboard and select Device Manager from the menu. Device Manager displays all the hardware devices connected to the computer.

Step 4: Check for Error Icons

In Device Manager, expand the Printers, Print Queues, or Universal Serial Bus Controllers section. Look for the printer. If there is a problem, the printer may not appear, or it may display a yellow warning icon (!), indicating that Windows cannot detect the device properly.

Step 5: Reconnect the Printer

Reconnect the printer's USB cable to the same or another USB port on the computer. Wait a few seconds for Windows to recognize the printer.

Step 6: Scan for Hardware Changes

In Device Manager, click the Action menu and select Scan for hardware changes. Windows will search for newly connected hardware and automatically detect the printer. If required, Windows will reinstall the necessary driver.

Step 7: Verify the Printer is Detected

After the scan is complete, check that the printer appears in Device Manager without any warning icons. Then open Settings → Bluetooth & devices → Printers & scanners and confirm that the printer status is Ready. Finally, print a Test Page to ensure the printer is working correctly.

- 4. A user reports that their webcam video is not displaying in Zoom, but it works in the default camera app. Troubleshoot and resolve the issue so the webcam works in both applications. Hint: Check if another app is using the webcam or if Zoom permissions are enabled.**

>>>

Step 1: Verify the Webcam

Open the Windows Camera app and check whether the webcam displays a live video. If the webcam works in the Camera app, it confirms that the webcam and its driver are functioning correctly.

Step 2: Close Other Applications

Close the Camera app and any other applications that may be using the webcam, such as Microsoft Teams, Skype, Google Meet, or OBS Studio. These applications can prevent Zoom from accessing the webcam.

Step 3: Check Zoom Camera Settings

Open Zoom and go to Settings > Video. Under the Camera section, make sure the correct webcam is selected from the drop-down list. If multiple cameras are listed, choose the correct one.

Step 4: Check Windows Camera Permissions

Open Settings > Privacy & Security > Camera. Make sure Camera access is turned On. Also, ensure that Let desktop apps access your camera is enabled so that Zoom can use the webcam.

Step 5: Restart Zoom

Close Zoom completely and open it again. Join a meeting or start a new meeting to check whether the webcam video is displayed.

Step 6: Restart the Computer

If the webcam still does not work in Zoom, restart the computer. This closes any background processes that may be blocking the webcam and refreshes the device settings.

Step 7: Verify the Solution

Open Zoom again and start or join a meeting. If the webcam displays video correctly in Zoom as well as in the Windows Camera app, the problem has been successfully resolved.