

DAY 1


1. Create a table listing 3 types of printers, 2 types of scanners, and 2 types of webcams, and for each, write one real-life use case (for example: 'Inkjet printer – printing college assignments').

Device Category	Type / Model	Real-Life Use Case
Printer	Inkjet Printer	Printing photo-quality family pictures and everyday color college assignments at home.
Printer	Laser Printer	Printing high-volume, black-and-white text invoices and contracts quickly in a corporate office.
Printer	Thermal Printer	Printing instant paper receipts and shipping barcode labels at retail checkout counters.
Scanner	Flatbed Scanner	Digitizing fragile historical documents, bound book pages, and old physical photo prints.
Scanner	Sheet-fed (Document) Scanner	Rapidly scanning large stacks of double-sided legal papers into searchable PDFs for a law firm.
Webcam	Integrated / Built-in Laptop Webcam	Attending informal remote team catch-ups and online university lectures on the go.
Webcam	External 4K USB Webcam	Streaming high-definition gaming content on Twitch or hosting polished client webinars.

2. Draw a labelled diagram showing how a typical home printer connects to a laptop or PC, including the connection interface used (USB, Wi-Fi, or Bluetooth).

1. USB Connection (Wired): This uses a physical USB-A to USB-B cable, connecting the printer directly to the PC's USB port. It is the most reliable, direct connection and requires no network configuration.

TYPICAL HOME PRINTER TO PC/LAPTOP CONNECTION INTERFACES




2. Wi-Fi Connection (Wireless Network): This method connects both the printer and the laptop to a central Wi-Fi router. This is the most common wireless setup as it allows multiple devices on the same network to print to the same printer.

3. Bluetooth Connection (Wireless P2P): Bluetooth establishes a direct, point-to-point wireless link between the laptop's Bluetooth radio and the printer's. This is an ad-hoc connection, useful for simple setups but generally has a shorter range than Wi-Fi.

3. List three different connection interfaces (such as USB, Wi-Fi, Bluetooth) used by peripherals like printers, scanners, and webcams, and for each, name one advantage and one disadvantage Hint :Think about speed, convenience, and compatibility.

>>>

1. USB (Universal Serial Bus)



Used by: Printers, scanners, and webcams.

Advantage:

USB provides a fast, reliable, and stable connection between the computer and the peripheral device. It is easy to install using the plug-and-play feature and does not require a network connection. It is ideal for tasks such as printing documents, scanning images, and using webcams for video calls.

Disadvantage:

USB requires a physical cable, so the device must remain close to the computer. It also uses one of the computer's USB ports, which may be limited.

2. Wi-Fi (Wireless Fidelity)



Used by: Wireless printers, network scanners, and some webcams.


Advantage:

Wi-Fi allows devices to connect without cables, making it possible to use the printer or scanner from multiple computers, laptops, tablets, or smartphones connected to the same network. It provides greater flexibility and reduces cable clutter.

Disadvantage:

The connection depends on the strength and stability of the Wi-Fi network. Weak signals, network congestion, or router problems can slow down communication or disconnect the device.

3. Bluetooth



Used by: Bluetooth-enabled printers, scanners, and webcams.

Advantage:

Bluetooth provides a simple wireless connection between nearby devices without requiring a Wi-Fi network. It is easy to pair devices and is useful for connecting laptops, smartphones, and tablets to peripherals over short distances.

Disadvantage:

Bluetooth has a limited range (usually about 10 meters) and slower data transfer speeds than USB or Wi-Fi. It is less suitable for transferring large files or performing high-speed tasks.

4. **Pick any one device you use at home or college (printer, scanner, or webcam). Write step-by-step instructions for how you would connect it to your computer, including what cable or wireless method you would use and any setup steps required.**

>>>

Step 1: Unpack and Place the Printer

Remove the printer from its packaging and place it on a flat, stable surface near your computer. Make sure there is enough space around the printer for proper ventilation and easy access to the paper tray and ink or toner cartridges.

Step 2: Connect the Power Cable

Take the power cable that came with the printer and plug one end into the printer's power port. Plug the other end into a wall power outlet. Ensure the connection is secure before proceeding.

Step 3: Turn On the Printer

Press the **Power** button on the printer. Wait for the printer to complete its startup process. Some printers may take a minute or two to initialize and prepare for use.

Step 4: Install Ink or Toner (If Required)

If this is the first time you are using the printer, open the printer cover and install the ink cartridges or toner cartridges according to the instructions provided by the manufacturer. Close the cover securely after installation.

Step 5: Load Paper into the Paper Tray

Pull out the paper tray and place a stack of clean paper into it. Adjust the paper guides so that they fit the paper correctly without bending it. Push the tray back into the printer.

Step 6: Connect the USB Cable

Take a USB printer cable and connect the square-shaped end to the USB port on the printer. Connect the flat USB end to an available USB port on your computer. Ensure both ends are firmly connected.

Step 7: Wait for the Computer to Detect the Printer

After connecting the USB cable, your computer will automatically detect the new printer. Windows will usually display a notification indicating that a new device has been found and is being set up.

Step 8: Install the Printer Driver

If Windows installs the driver automatically, wait until the installation is complete. If the driver is not installed automatically, use the installation CD that came with the printer or download the latest driver from the printer manufacturer's official website. Follow the on-screen instructions to complete the installation.

Step 9: Verify the Printer Installation

Open Settings and go to Bluetooth & devices > Printers & scanners (or open Control Panel > Devices and Printers on older versions of Windows). Check that your printer appears in the list of installed devices. This confirms that the computer has recognized the printer successfully.

Step 10: Set the Printer as the Default Printer

If you plan to use this printer regularly, right-click on the printer's name and select Set as Default Printer. This ensures that documents are sent to this printer automatically unless another printer is selected.

Step 11: Print a Test Page

Right-click on the printer, select Printer Properties, and click Print Test Page. The printer should print a sample page. Check that the text and images print clearly and that there are no errors.

Step 12: Start Using the Printer

Once the test page has printed successfully, the printer is fully connected and ready to use. You can now print documents, photos, assignments, and other files from any application by selecting the printer from the Print menu.