

ANOVA 1-Way:						
Effect	Degrees of Freedom (df)	F-statistic (MS / MS residual)	P-value	Interpretation of P-value Explain		
Turbines	3	1800	<0.01	A P-value of <0.01 means extremely strong confidence that the groups are different.		
Residual	19	-	-	-	-	-