

Assignment 2.3: Peripheral Troubleshooting Theory

Task 1: List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Table 1. Issues and solution

Issue	Possible Solution
Keyboard or mouse is not detected.	Reconnect the USB cable or try a different USB port
Keyboard keys or mouse buttons are not working	Restart the computer and check if the device works properly
Mouse cursor is not moving	Clean the mouse sensor and try using it on a proper surface
Keyboard types incorrect characters	Check the keyboard language/layout settings in Windows
Device disconnects frequently	Update the USB drivers or use another USB port

Task 2: Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step 1: Turn on the Bluetooth headphones and make sure are fully charged.

Step 2: Enable Bluetooth on the phone by going to: **Settings -> Bluetooth**.

Step 3: Check whether the headphones are in **pairing mode**.

Step 4: Look for the headphone name in the list of available Bluetooth devices.

Step 5: Tap the headphone name to connect.

Step 6: If the connection fails, turn Bluetooth **OFF** and then **ON** again.

Step 7: If the headphones are already paired but not connecting, select the device and choose Forget Device, then pair it again.

Step 8: Restart the phone and the headphones.

Step 9: Check whether the headphones are already connected to another device and disconnect them if necessary.

Step 10: After reconnecting, play audio to confirm the headphones are working correctly.

Task 3: A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem. Hint: Consider device manager, privacy settings, and app permissions.

- Check that the webcam is securely connected to the USB port.
- Try connecting the webcam to a different USB port.
- Open Device Manager and check if the webcam appears without any warning symbol.

- Go to **Settings -> Privacy -> camera** and ensure Camera access and Allow desktop apps to access your camera are enabled.
- Open **Zoom -> Settings -> Video** and make sure the correct webcam is selected.
- Restart the computer or update/reinstall the webcam driver if the issue continues.

Task 4: You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Step 1: Turn on the printer and make sure it is properly connected to the computer

Step 2: Open **Settings -> System -> Troubleshoot -> Other troubleshooters**.

Step 3: Find Printer and click run next to it.

Step 4: Select the printer that is showing the Offline status.

Step 5: Wait while Windows scans for printer-related problems.

Step 6: Follow the on-screen instructions if windows suggest a fix (Such as setting the printer as the default printer or reconnecting it)

Step 7: After the trouble shooting is complete, print a test page to check whether the issue has been resolved.