

AT Commands

Ali Mirghasemi



Introduction

- AT commands, short for Attention commands, are a set of instructions used in the field of telecommunications and data communication.
- The "AT" prefix stands for "Attention," signaling that the following characters are commands to be interpreted by a device, typically a modem or a mobile phone.
- These commands have been a crucial part of communication protocols for decades, providing a standardized way for devices to communicate with each other



Applications

• Modems

• AT commands are widely used in dial-up modems for establishing and managing communication over telephone lines. They enable tasks such as dialing, answering calls, and configuring communication parameters.

Mobile Phones

• In the context of mobile phones, AT commands are used for tasks like sending SMS (Short Message Service), making calls, querying network information, and configuring settings. These commands play a crucial role in the communication between the mobile device and the cellular network.

Embedded Systems

• AT commands are also employed in embedded systems, where devices need to communicate with each other or with a central control unit. This can include IoT (Internet of Things) devices, where AT commands help in configuring communication parameters and controlling device behavior.

Bluetooth Devices

• AT commands are used in Bluetooth modules to configure settings, establish connections, and manage data transfer between devices.



AT Command (Send)

Action	Format	Example
Execute	AT+ <cmd><cr><lf></lf></cr></cmd>	AT+RESET <cr><lf></lf></cr>
Set	AT+ <cmd>=<params><cr><lf></lf></cr></params></cmd>	AT+CMGF=1 <cr><lf></lf></cr>
Get	AT+ <cmd>?<cr><lf></lf></cr></cmd>	AT+CMGF? <cr><lf></lf></cr>
Help	AT+ <cmd>=?<cr><lf></lf></cr></cmd>	AT+CMGF=? <cr><lf></lf></cr>
CMD Param	AT <cmd><param/><cr><lf></lf></cr></cmd>	ATE0 <cr><lf></lf></cr>
CMD	AT <cmd><cr><lf></lf></cr></cmd>	AT&F <cr><lf></lf></cr>
Test	AT <cr><lf></lf></cr>	AT <cr><lf></lf></cr>



AT Command (Response)

State	Format	Example
Ok	<cr><lf>OK<cr><lf></lf></cr></lf></cr>	<cr><lf>OK<cr><lf></lf></cr></lf></cr>
ERROR	<cr><lf>ERROR<cr><lf></lf></cr></lf></cr>	<cr><lf>ERROR<cr><lf></lf></cr></lf></cr>
Get Value	<cr><lf>+<cmd>: <params><cr><lf> <cr><lf>OK<cr><lf></lf></cr></lf></cr></lf></cr></params></cmd></lf></cr>	<cr><lf>+CMGF: 1<cr><lf><cr><lf>OK<cr><lf></lf></cr></lf></cr></lf></cr></lf></cr>
Notification Params	<cr><lf>+<id>: <params><cr><lf></lf></cr></params></id></lf></cr>	<cr><lf>+CMTI: "SM", 1<cr><lf></lf></cr></lf></cr>
Notification	<cr><lf><notification><cr><lf></lf></cr></notification></lf></cr>	<cr><lf>RING<cr><lf></lf></cr></lf></cr>



