CANBUS STATE DIAGRAM

POWER ON

START UP

SEND CAL SIGNAL

CALIBRATING

CALIBRATION COMPLETE

RUNNING

ERROR /
NOT ALL BOARDS RESPOND IN TIME

ERROR