Ex No: 5

Customize Switch with Network Modules Using Cisco packet Tracer

Aim:

To customize a modular switch in Cisco packet Tracer by adding Fast ethernet and gigabit Fiber network modules and verifying the interface.

Procedure:

1. Open Cisco packet Tracer and Select Network Devices => switches → Switch - PT Empty.
2. Add 2 PCs and 1 Router 2911 to workspace
3. Open the switch → physical tab → power off
4. Add modules

   PT-Switch-NM-1CFE to Slot 0,1,2 (CFE)
5. Power on the switch and wait for the IOS prompt
6. Open CLI

```
Switch>enable
Switch# show ip interface brief
```

7. Connect

   PC0 → Fast Ethernet 0/1 using Co

   PC1 → Fast Ethernet 1/1

using Copper straight Through gigabit Ethernet 0/0

8. Configure IP addresses on the PCs and use ping to test connectivity

Module Reference:

Connection	Module	Cable
PC0 → switch	Fast Ethernet 0/1	CRE (Copper straight - Through)

PC1 -> Switch	Fast Ethernet	CFE
Router -> Switch	Gigabit Ethernet	CFE

Result:

The modular switch was successfully customized with two FastEthernet ports and one gigabit Fiber port and the Interfaces were verified using Cisco IOS CLI

Output:

