

NOTES

1. Log in Information:
 - . **Username:** <username for Pi>
 - . **Password:** <password for Pi>
2. **Shut down the PI** computer **before removing or connecting** components.
3. Handle wires carefully while plugging them on breadboard. **Do not press them hard.**
4. Insert resistors into breadboard very carefully. **Do not twist them too much.**
5. Make sure you connect wires to correct pin numbers as given in instructions.
6. Keyboard shortcuts for Coding:
 - . Press **shift key** and **2 key** above w key **together** to insert quotes “ “
 - . Press the **| key** above the Enter key **to insert a #** symbol
 - . Press **Ctrl Key** and **S key** together **to save** your program
 - . Click on the **Green button to Start** your program
 - . Click on the **Red button to Stop** your program
7. When you click on a file to open it wait for few seconds.