
CO1(DAC)

The design of machine elements involves a systematic and structured approach to creating individual components that make up a mechanical system or machine.

General procedure for designing machine elements:



Define the Problem and Requirements: Begin by understanding the problem you need to solve and the functional requirements of the machine element. Consider factors such as load, speed, temperature, and environment.

Gather Design Data: Collect data and information relevant to the design, including material properties, manufacturing processes, and safety standards.

Conceptual Design: Generate initial design concepts that meet the functional requirements. This is a creative phase where you explore different ideas and configurations.

Preliminary Sizing and Analysis: Estimate the size and dimensions of the machine element based on the conceptual design. Perform preliminary calculations and analysis to ensure feasibility.

Material Selection: Choose appropriate materials for the machine element based on factors like strength, stiffness, wear resistance, and cost. Consider the availability and manufacturability of the chosen material.

Detailed Design: Create a detailed design of the machine element, including precise dimensions, tolerances, and features. Use engineering software and calculations to refine the design.

Load and Stress Analysis: Perform load and stress analysis to ensure that the machine element can withstand the expected loads and forces without failure. Consider factors like static and dynamic loads, fatigue, and thermal effects.

Safety and Factor of Safety: Incorporate safety factors into your design to account for uncertainties and variations in operating conditions. Calculate the factor of safety to ensure the component's reliability.

Manufacturability and Cost Analysis: Assess the manufacturability of the design by considering the chosen manufacturing processes (e.g., machining, casting, forging). Evaluate the cost implications of the design choices. Create detailed engineering drawings and documentation that include dimensions, tolerances, material specifications, and assembly instructions.

Principles Of Ergonomics

Ergonomics, also known as human factors engineering, is the study of designing and arranging products, systems, and environments to fit the needs, capabilities, and limitations of human users. The principles of ergonomics aim to improve safety, comfort, efficiency, and overall well-being for individuals in their interactions with various systems and designs.

key principles of ergonomics:

User-Cantered Design:

Ergonomics starts with a user-cantered approach. Designers must understand the abilities, limitations, and preferences of the target users to create products and environments that accommodate their needs effectively.

Anthropometry:

Anthropometry involves the measurement of human body dimensions and proportions. Design should account for variations in body size, shape, and mobility to ensure that products and spaces are suitable for a diverse user population.

Task Analysis:

Understanding the tasks users need to perform is crucial. Analyzing tasks helps designers optimize the design for efficiency, comfort, and safety. This includes considering the sequence of actions, force requirements, and duration of tasks.

Feedback and Control:

Providing clear and timely feedback to users about the status of a system or the results of their actions is essential. Additionally, users should have control over the system and be able to adjust settings or take corrective actions when necessary.

Minimize Repetitive Motion:

Ergonomic designs aim to reduce repetitive and excessive movements that can lead to musculoskeletal disorders. This includes optimizing workstations, tools, and equipment to minimize awkward postures and repetitive actions.

Reduce Excessive Force:

Design should minimize the need for users to exert excessive force when interacting with products or systems. This can involve using mechanical aids, adjusting leverage, or providing ergonomic grips.

Maintain Neutral Postures:

Users should be able to maintain natural and neutral body postures when performing tasks. Design should avoid forcing users into awkward or uncomfortable positions.

Visibility and Accessibility:

Information, controls, and objects should be easily visible and accessible. Users should not need to strain or stretch excessively to reach or see what they need.

Clear Communication:

Effective communication is vital, both in terms of design feedback and the clarity of instructions or labels. Use intuitive symbols, colors, and signage to convey information.

Safety:

Safety is a primary concern in ergonomics. Designs should minimize the risk of accidents, injuries, and exposure to hazards. This includes proper machine guarding, safety protocols, and emergency procedures.

Environmental Factors:

Ergonomics considers environmental factors like lighting, noise, temperature, and air quality. These factors can impact user comfort and performance and should be optimized accordingly.

Training and Education:

Users should receive adequate training and education on how to use products or systems safely and effectively. Instructions should be clear and easily accessible.

Feedback and Evaluation:

Continuously gather feedback from users and conduct evaluations to identify areas for improvement. Ergonomics is an iterative process that can lead to ongoing refinements in design.

Compliance with Standards:

Ensure that designs adhere to relevant ergonomic standards and guidelines, which may vary by industry and region.

Consideration of Special Populations:

Recognize that different user groups, such as the elderly or individuals with disabilities, may have unique ergonomic requirements. Design should accommodate these populations whenever possible.

Aesthetics In Designing Automobile Components

Aesthetics play a crucial role in designing automobile components. The appearance and visual appeal of a vehicle can significantly influence consumer preferences and purchasing decisions. Here are some key considerations for incorporating aesthetics into the design of automobile components:

Brand Identity: Vehicle manufacturers often have a distinct design language that reflects their brand identity. Designers must adhere to this established aesthetics to maintain brand recognition and consistency across their product lines.

Form and Proportion: The overall form and proportion of automobile components, such as the body panels, grille, headlights, and taillights, should be visually pleasing and harmonious. Proportional balance is essential to create a sense of stability and elegance.

Sculptural Elements: Designers often use sculptural elements to give car parts depth and dimension. These elements can include contours, curves, and embossed or debossed surfaces to create a sense of movement and visual interest.

Material Selection: The choice of materials can significantly impact the aesthetics of automobile components. High-quality materials with the right texture and finish can enhance the perceived value of the vehicle.

Color and Finish: The color palette and finish of automobile components should be carefully selected to complement the overall design theme. Color can evoke emotions and influence perception, while the finish (e.g., glossy, matte, metallic) can enhance the component's visual appeal.

Lighting Design: Lighting components, such as headlights, taillights, and interior lighting, are crucial for both functionality and aesthetics. LED technology has opened up new possibilities for creative lighting designs that can set a vehicle apart.

User Interface Design: As vehicles become more technologically advanced, the design of the user interface components, including touchscreens, buttons, and controls, must be intuitive, visually appealing, and easy to use.

Safety Considerations: While aesthetics are essential, safety should never be compromised. Safety components, such as airbags and crumple zones, must be integrated seamlessly into the vehicle's design without sacrificing aesthetics.

Environmental Sustainability: A growing concern in automobile design is sustainability. Aesthetically pleasing components can be made from eco-friendly materials and designed with a focus on reducing waste and emissions.

Consumer Feedback: Conducting consumer research and gathering feedback on design concepts and prototypes is essential. Understanding consumer preferences and incorporating them into the design process can lead to more attractive and marketable automobile components.

Trends and Innovation: Staying up-to-date with current design trends and technological innovations is vital for designing components that are not only visually appealing but also cutting-edge.

Cohesive Interior and Exterior: The interior and exterior of a vehicle should have a cohesive design language to create a unified and aesthetically pleasing overall experience for the driver and passengers.

Factors governing the design of machine parts

Functionality: The primary function of the machine part determines its design. The part should perform its intended task accurately and efficiently. Engineers must consider factors such as load-bearing capacity, precision, speed, and range of motion.

Material Selection: The choice of materials is crucial in designing machine parts. Engineers must consider factors like material strength, stiffness, corrosion resistance, and cost. The material should be suitable for the specific application and operating environment.

Safety: Safety is paramount in machine design. Machine parts should be designed to minimize the risk of accidents or injury to operators and maintenance personnel. This includes features like guards, emergency stops, and fail-safe mechanisms.

Durability: Machine parts need to withstand various stresses, including mechanical, thermal, and environmental. Design considerations should include factors like fatigue resistance, wear resistance, and resistance to environmental factors like moisture, chemicals, and temperature extremes.

Cost: Cost considerations are essential in designing machine parts. Engineers must balance performance and durability requirements with cost constraints. This includes not only the cost of materials but also manufacturing and maintenance costs.

Manufacturability: Machine parts must be designed with manufacturability in mind. The design should be optimized for efficient and cost-effective production processes, such as machining, casting, forging, or additive manufacturing.

Ease of Assembly: Ease of assembly is crucial for reducing production time and ensuring that the parts fit together correctly. Designers should consider features like standardized fasteners, alignment guides, and tolerances to facilitate assembly.

Tolerances and Fits: Proper tolerances and fits are essential to ensure that machine parts function correctly when assembled. Designers must specify tolerances that allow for the required clearances and interference fits where necessary.

Serviceability and Maintenance: Designing for ease of maintenance is critical. Machine parts should be accessible for inspection, repair, and replacement when necessary. This includes considerations like access panels, removable components, and standardized fasteners.

Weight and Size: The weight and size of machine parts impact transportation, handling, and overall system efficiency. Designers must optimize weight and size while meeting performance requirements.

Environmental Considerations: Machine parts may be exposed to various environmental conditions. Designers should consider factors like temperature, humidity, exposure to chemicals, and the potential for corrosion when selecting materials and coatings.

Design Stress, Working stress and Factor of Safety

Design Stress:

Definition: Design stress, also known as allowable stress or nominal stress, is the maximum stress that a material or component is designed to experience under normal operating conditions. It is a calculated value based on the material properties, intended use, and safety factors.

Working Stress:

Definition: Working stress, also known as actual stress or operating stress, is the stress that a material or component experiences while in service or during normal operation. It is the actual load or force applied to the structure or component divided by the cross-sectional area.

Factor of Safety:

Definition: The factor of safety (FoS) is a dimensionless ratio that represents the margin of safety between the design stress and the working stress. It is calculated by dividing the design stress by the working stress.

Calculation: FoS = Design Stress / Working Stress

Purpose: The factor of safety is a critical concept in engineering design. A higher FoS indicates a larger safety margin, meaning that the design is more robust and less likely to fail under unexpected or extreme conditions. Engineers typically choose an appropriate factor of safety based on the level of risk they are willing to accept and the criticality of the application.


Stress - strain diagram for ductile.

A stress-strain diagram is a graphical representation of the relationship between stress (force per unit area) and strain (deformation) for a material. The behavior of materials can be broadly classified into two categories: ductile and brittle. The stress-strain diagrams for these two types of materials exhibit distinct characteristics.

Ductile Material:

A ductile material, such as most metals (e.g., steel, aluminum, copper), can undergo significant plastic deformation before it fractures. Here's what the stress-strain diagram for a ductile material typically looks like:

Stress-Strain Diagram for Ductile Material



Elastic Region (Linear): Initially, as stress is applied, the material exhibits linear elastic behavior. This

means that stress is directly proportional to strain, and the material returns to its original shape when

the load is removed.

Yield Point (Yield Strength): Beyond a certain point called the yield point, the material starts to

undergo plastic deformation. This is the beginning of the plastic region. The yield strength is the stress

at which this transition occurs.

Plastic Region: In the plastic region, the material continues to deform without a proportional increase

in stress. Plastic deformation is permanent, and the material undergoes necking, where localized

thinning occurs.

Ultimate Tensile Strength (UTS): The maximum stress that the material can withstand before failure

occurs is called the ultimate tensile strength. It is the highest point on the stress-strain curve.

Necking: As the material approaches failure, it undergoes significant necking, reducing its cross-

sectional area.

Fracture Point: The material ultimately fractures when it can no longer support the applied load.

Maximum principal stress theory.

The Maximum Principal Stress Theory, also known as the Rankine Theory or the Maximum Normal

Stress Theory, is a criterion used in material science and structural engineering to predict the failure of

materials subjected to complex stress states. This theory is primarily applied to ductile materials like

metals and alloys. The main principle behind this theory is that a material fails when the maximum

principal stress reaches a critical value.

Maximum shear stress theory

The Maximum Shear Stress Theory, also known as the Tresca Criterion or Guest's Criterion, is a failure

criterion used in material science and structural engineering to predict the yielding or failure of materials

subjected to complex stress states. This theory is typically applied to materials that exhibit ductile

behaviour, such as metals and alloys. The main principle behind this theory is that a material fails when

the maximum shear stress at a point reaches a critical value.

Kinematic Link or Element:

8

A kinematic link, also known as a kinematic element or simply a link, is a rigid or semi-rigid component within a machine or mechanism. Links can be thought of as the building blocks of a mechanism, and they are connected by various joints or connections.

Kinematic Pair:

A kinematic pair refers to the connection between two links that allows relative motion between them. Kinematic pairs are fundamental in defining the behaviour of mechanisms. There are two main types of kinematic pairs: lower pair and higher pair.

Lower Pair:

A lower pair is a kinematic pair in which the two links have surface contact or contact along a line. Lower pairs include revolute joints (pin joints) and prismatic joints (sliding joints). Revolute joints allow rotational motion, while prismatic joints allow translational motion. Lower pairs are common in many mechanical systems.

Higher Pair:

A higher pair is a kinematic pair in which the two links have point contact. Higher pairs include spherical joints, planar joints, and cylindrical joints. These joints allow more complex relative motion, and they often involve rolling or sliding contact.


Kinematic Chain:

A kinematic chain is a combination of links and joints that are connected in a specific manner to transmit motion and force. A kinematic chain can be open or closed. An open kinematic chain is not connected to form a loop, while a closed kinematic chain is connected to form a loop or a closed path. Kinematic chains are the foundation of analysing and designing mechanical systems and machines.

constrained motion

Completely constrained motion

refers to a situation in which an object or body is restricted from moving in any direction within a given space or plane. In other words, all possible degrees of freedom of the object are constrained, leaving it with no independent motion. Completely constrained motion is a common concept in mechanical engineering, robotics, and kinematics, especially when designing mechanisms and machines.



Here are a few key points about completely constrained motion:

Degrees of Freedom (DOF): In mechanical systems, the concept of degrees of freedom refers to the number of independent ways an object can move in a given space. For a rigid body in three-dimensional space, there are typically six degrees of freedom: three translational (along the X, Y, and Z axes) and three rotational (about the X, Y, and Z axes).


Complete Constraint: When all six degrees of freedom of a rigid body are constrained or restricted in a system, it is said to have completely constrained motion. This means the object cannot move or rotate independently in any direction.

Applications: Completely constrained motion is often desirable in certain engineering applications. For example, in machine design, it ensures that components move in a precise and controlled manner. In robotics, it can be essential for achieving accurate positioning and control of robot end-effectors.

Examples: Completely constrained motion can be achieved through various means, including fixed supports, bearings, guides, and other mechanical elements. For instance, a wheel rolling on a smooth, flat surface is completely constrained in its motion because it can only move in one direction (translation) and cannot rotate independently.

incompletely constrained motion,

also known as partially constrained motion, refers to a situation in which an object or body has some degrees of freedom (DOF) restricted but is not completely restricted from moving in a given space or plane. In other words, the object can move or rotate independently in at least one direction or about one axis while being constrained in other directions or axes. Incompletely constrained motion is a common scenario in various mechanical systems and machines.



Here are some key points about incompletely constrained motion:


Degrees of Freedom (DOF): Degrees of freedom represent the number of independent ways an object can move in a given space. For a rigid body in three-dimensional space, there are typically six degrees of freedom: three translational (along the X, Y, and Z axes) and three rotational (about the X, Y, and Z axes).

Partial Constraint: In incompletely constrained motion, not all of the six degrees of freedom are restricted. One or more DOFs are allowed to vary, while others are constrained or restricted.

Applications: Incompletely constrained motion is common in many engineering applications, especially when designing mechanical systems that require some freedom of movement for functionality. Examples include robotic arms, vehicles with suspension systems, and many types of machinery.

Successfully constrained motion

refers to a situation in which an object or body's motion is intentionally and effectively controlled or restricted according to design requirements. In this context, "successful" means that the constraints or restrictions imposed on the object's motion align with the desired objectives of the system or machine. Successfully constrained motion is a fundamental concept in engineering and mechanical design, as it ensures that a system functions as intended while meeting safety, stability, and performance criteria.



Here are some key points about successfully constrained motion:

Controlled Degrees of Freedom (DOF): In engineering systems, successful constrained motion often involves specifying which degrees of freedom (DOFs) are allowed to move or rotate and which are constrained or restricted. By carefully controlling these DOFs, engineers can achieve desired outcomes.

Design Objectives: The success of constrained motion is determined by whether it aligns with the design objectives and requirements of the system. These objectives may include safety, stability, accuracy, efficiency, and functionality.

Types of Constraints: Successful constrained motion can take various forms, depending on the application. Constraints can be imposed through mechanisms, joints, linkages, supports, or other mechanical elements. The type and nature of constraints depend on the desired behavior of the system.

Examples of Successful Constrained Motion:

A robotic arm that precisely follows a predefined path while maintaining accuracy and repeatability.

A vehicle suspension system that effectively dampens vibrations and provides a comfortable ride while restricting vertical motion.

A CNC (Computer Numerical Control) machine that accurately positions a cutting tool while constraining undesirable vibrations or deflections.

Definition of Machine, Structure and Mechanism. Difference between Machine,

Mechanism and Structure.

Machine:

A machine is a mechanical device designed to perform a specific task or function by using mechanical power. Machines typically consist of a combination of moving parts, such as gears, levers, pulleys, and motors, that work together to transform input energy into useful work output. Machines are engineered to perform tasks efficiently and may serve a wide range of purposes, from simple machines like a lever to complex machines like an automobile engine or a CNC milling machine.

Structure:

A structure is a framework or assembly of elements designed to support loads, resist forces, or provide stability. Structures are typically stationary and do not perform mechanical work or have moving parts for a specific purpose. Examples of structures include bridges, buildings, dams, and support frames. While structures are essential for civil engineering and architecture, they do not have the dynamic components found in machines.

Mechanism:

A mechanism is a combination of parts arranged to achieve a specific motion or task through the interaction of components. Mechanisms are often integral to machines, enabling them to perform their intended functions. Unlike machines, mechanisms focus on the movement and coordination of parts rather than the overall performance of a task. Examples of mechanisms include gear trains, linkages, cams, and crankshafts. Mechanisms can be found in various engineering applications, including machines, robotics, and automotive systems.

Differences between Machine, Mechanism, and Structure:

Purpose:

Machine: Machines are designed to perform specific tasks or work functions efficiently. They are meant to accomplish mechanical work.

Mechanism: Mechanisms are designed to produce specific motions or movements, often as part of a machine's operation.

Structure: Structures are designed primarily to support loads, provide stability, or enclose spaces. They do not perform specific mechanical tasks or motions.

Components:

Machine: Machines contain a combination of components and mechanisms to accomplish tasks. They often have moving parts, power sources, and control systems.

Mechanism: Mechanisms consist of interconnected components that create specific motions or transformations. They may or may not be part of a machine.

Structure: Structures are typically composed of stationary elements like beams, columns, and foundations. They lack the dynamic components and moving parts found in machines and mechanisms.

Motion:

Machine: Machines may involve mechanisms to generate controlled motion, but their primary focus is on accomplishing work or tasks.

Mechanism: Mechanisms are explicitly designed to produce desired motions or transformations.

Structure: Structures do not have inherent motions or mechanisms for specific movements; they provide support and stability.


Examples:

Machine: Automobiles, lathes, sewing machines, and conveyor belts.

Mechanism: Four-bar linkages, gear trains, and cam-follower systems.

Structure: Bridges, skyscrapers, dams, and support frames.

A four-bar chain,




also known as a four-bar linkage, is a mechanical system consisting of four rigid bars (or links) connected by four joints. These joints are typically revolute (hinge) joints, allowing for rotational motion. The four-bar chain forms a closed loop, and its behavior depends on the arrangement and lengths of the links and the location of the joints. Four-bar chains are used in engineering to create various types of mechanisms for controlled motion and force transmission, such as in engines, robotics, and automotive systems. The specific configuration of the four bars determines the type and characteristics of motion achieved by the mechanism.

Inversion of single slider mechanism

1. Oscillating cylinder engine –


- 2. Crank and slotted lever quick return mechanism –
- 3. Bull Engine (Pendulum pump)

1. Oscillating cylinder engine –



An oscillating cylinder engine is a type of steam engine where the cylinder, containing the piston, pivots or oscillates on a fixed axis instead of moving in a linear reciprocating motion. This unique design simplifies the engine's construction, as it eliminates the need for complex mechanisms like connecting rods and slide valves. Oscillating cylinder engines are compact, lightweight, and have been used in applications like small stationary engines and model steam engines. They require a source of steam, often provided by a boiler, to push the piston within the oscillating cylinder. While not as efficient as some other steam engines, they are appreciated for their simplicity and historical significance.


2. Crank and slotted lever quick return mechanism –



A crank and slotted lever quick return mechanism is a mechanical linkage that converts rotary motion into reciprocating motion with one direction of the reciprocation being faster than the other. It consists of a crank (rotating part) and a slotted lever (reciprocating part) that is attached to a slider moving along a slotted guide. As the crank rotates, it drives the slider back and forth within the slot in the lever. The return stroke of the slider is quicker than the forward stroke due to the eccentricity of the crank's rotation. This mechanism is commonly used in machines like shapers and slotting machines to achieve fast cutting or shaping motions in one direction and controlled return motions in the other direction, allowing for efficient machining operations.


Inversions of double slider crank chain

3. Elliptical Trammel:




An elliptical trammel, also known as a "trammel of Archimedes," is a mechanical device used for drawing ellipses. It consists of a fixed frame with two sliders connected to each other by a bar. One slider moves along the major axis of the ellipse (longest diameter), while the other slider moves along the minor axis (shortest diameter). By adjusting the positions of the sliders and the length of the connecting bar, one can create ellipses of various sizes and proportions. The elliptical trammel is named after the ancient Greek mathematician Archimedes, who is credited with its invention.

4. Scotch Yoke:



A Scotch yoke is a mechanism used to convert rotary motion into reciprocating linear motion (or vice versa). It consists of a circular disc (the yoke) with a slot in it and a connecting rod attached to a sliding block that moves within the slot. As the disc rotates, the sliding block moves back and forth in a straight-line motion. The motion of the sliding block is sinusoidal, resulting in a quick forward stroke and a slower return stroke. Scotch yokes are often used in various applications, including engines, pumps, and other machinery that requires reciprocating motion.

5. Oldham's Coupling:



Oldham's coupling, also known as an "Oldham coupling" or "sliding block coupling," is a type of flexible coupling used to connect two shafts that are misaligned but parallel to each other. It consists of three discs: one central disc with a slot, and two outer discs that fit into the slot. The central disc is attached to one shaft, and the outer discs are attached to the other shafts. When the central shaft rotates, the outer shafts are able to rotate while maintaining parallel alignment. Oldham's couplings are used to transmit torque between misaligned shafts while allowing for slight axial movement and accommodating angular misalignment.