

SESA2024 Astronautics

Chapter 6: Attitude Control



Contents

Attitude Control Introduction

Rotational Dynamics

Momentum Management

Spacecraft Categories

Torques and Torquers


Attitude Sensors

On-board processing

Impact of the ACS on the Spacecraft System



Basic motion: Consider a body in orbit (with no disturbances)...





Primary Purposes of the Attitude Control System (ACS) are:

- To achieve the pointing requirements of the **payload**, in terms of directions, accuracy, stability, etc.
 - e.g. Earth pointing (comms payload, remote sensing payload, ...)

 Diverse directions (astronomical observatory, ...)
- To achieve the pointing requirements for "house-keeping", in all phases of the mission
 - e.g. Power raising Sun pointing

 Communications Earth pointing


 Thermal dissipation Deep space

 Thrust vector direction for rocket engine firing
- To 'manage the overall (angular) momentum' of the spacecraft to achieve its pointing mission.



Typical ACS operation showing flow of information:

In situations where a satalite passes through thin parts of the atmosphere the large thin areas (such a solar panels) can have a non uniform tiny rotational force applied, which adds up over the cuarse of many orbits.



So... we need to consider the rotational motion of spacecraft about its Centre of Mass (CM), and torques about the CM.



Linear Momentum

a 'stepping-stone' to translational/orbit dynamics

$$\mathbf{L} = \mathbf{MV}$$
vector scalar vector

Newton's second law:


$$\frac{d}{dt}(\mathbf{L}) = \frac{d}{dt}(M\mathbf{V}) = \sum_{ext} \mathbf{F}_{ext}$$

Free Motion:

• No Force, $\Sigma \mathbf{F}_{\text{ext}} = \mathbf{0} \Rightarrow \text{Momentum } \mathbf{L} \text{ is constant}$



Angular Momentum – *Inertia*, one dimension



Is the angular momentum the same?



Angular Momentum – *Inertia*, rotational vectors


For this one dimensional

motion:

$$\mathbf{H} = I_{xx} \mathbf{\omega}$$
vector scalar vector

Newton's second law:

$$\frac{d}{dt}(\mathbf{H}) = \frac{d}{dt}(I_{xx}\mathbf{\omega}) = \sum \mathbf{T}_{ext}$$



Free Motion:

No torque,
$$\sum \mathbf{T}_{ext} = 0 \Rightarrow \text{Momentum } \mathbf{H} \text{ is constant }$$




Angular Momentum – *In three dimensions*

In three dimensions:

$$\mathbf{\omega} = \begin{pmatrix} \omega_x \\ \omega_y \\ \omega_z \end{pmatrix}$$


Angular momentum:

$$\mathbf{H} = \mathbf{I} \boldsymbol{\omega}$$
vector matrix vector





Angular Momentum – *in three dimensions*



Free Motion:

• No torque, $\Sigma T_{ext} = 0 \Rightarrow Momentum H$ is constant



Angular Momentum – the inertia matrix

Angular momentum of a rigid body such as the main structure of a

$$[\mathbf{I}] = \begin{pmatrix} I_{xx} & -I_{xy} & -I_{xz} \\ -I_{xy} & I_{yy} & -I_{yz} \\ -I_{xz} & -I_{yz} & I_{zz} \end{pmatrix}$$

Inertia Matrix referred to Centre of Mass

 I_{xx} , I_{yy} , I_{zz} are Moments of Inertia

 I_{xy} , I_{yz} , I_{zx} are Products of Inertia

Products of inertia are a measure of unbalance, and cause 'cross-coupling'



Angular Momentum

$$\mathbf{H} = [\mathbf{I}] \boldsymbol{\omega}$$

$$\mathbf{H} = \begin{pmatrix} I_{xx} & -I_{xy} & -I_{xz} \\ -I_{xy} & I_{yy} & -I_{yz} \\ -I_{xz} & -I_{xz} & I_{zz} \end{pmatrix} \begin{pmatrix} \omega_x \\ \omega_y \\ \omega_z \end{pmatrix}$$

So the components of the angular momentum vector are:

$$\mathbf{H} = \begin{pmatrix} \left(I_{xx} \boldsymbol{\omega}_{x} - I_{xy} \boldsymbol{\omega}_{y} - I_{xz} \boldsymbol{\omega}_{z} \right) \\ \left(I_{yy} \boldsymbol{\omega}_{y} - I_{yz} \boldsymbol{\omega}_{z} - I_{xy} \boldsymbol{\omega}_{x} \right) \\ \left(I_{zz} \boldsymbol{\omega}_{z} - I_{xz} \boldsymbol{\omega}_{x} - I_{yz} \boldsymbol{\omega}_{y} \right) \end{pmatrix}$$




The Inertia Matrix



[I] is an important quantity when sizing up the control system inputs for any vehicle.




Rotational Motion – Gyroscopic precession






Rotational Motion – Gyroscopic precession




The rotational displacement occurs 90 degrees later in the direction of rotation.



Rotational Motion








Rotational Motion – momentum bias

Momentum reduces sensitivity to torque – gyroscopic rigidity


During δt , the momentum changes direction $\delta \psi$ from $\mathbf{H_0}$ to $\mathbf{H_1}$



Southampton

Momentum 'Management'

• The ACS must 'manage' the momentum **H** of the spacecraft, using control torquers to do so.



• This can be achieved using the principles of:

Conservation of momentum - using internal torquers to store/transfer momentum, Gimballing

 $(\Sigma \mathbf{T}_{\mathrm{ext}} = \mathbf{0} \Rightarrow \mathsf{Momentum} \mathbf{H} \mathsf{is constant})$

Newton's second law - using external torquers to apply a torque to the satellite

 $(\Sigma \mathbf{T}_{ext} \neq \mathbf{0} \Rightarrow Momentum \mathbf{H} \text{ changes in magnitude/direction})$

Southampton Southampton

Momentum 'Management'

Notes:

- 1) Momentum build-up
 - External disturbance torques (e.g. aerodynamic disturbances, etc) will cause a progressive build-up of angular momentum
- 2) Only external torques affect the total angular momentum of the system... ... therefore spacecraft must carry external torquers (e.g. thrusters, magnetorquers, etc) if angular momentum is to be controlled.

Momentum Bias is a method commonly used to provide inherent stability.


But

- to use momentum bias, it is desirable that one body axis of the spacecraft remains invariantly pointing (usually perpendicular to the orbit plane)
- bias also introduces an oscillatory nutation mode
- a system with bias will have different torque responses




Momentum 'Management'

Torque response without bias



Torque response with bias




A constant torque can precess the bias direction at rate:

$$\dot{\theta} = T/H_{0}$$
, $H_{0} = H_{bias}$




Spacecraft Categories





Spacecraft Categories





Spacecraft Categories - Spinner

Equation makerers use of intertia matix

Pure Spin Stabilisation

$$\mathbf{H} = [I] \mathbf{\omega}$$

- whole spacecraft body spins at a rate of typically 10 to 60 rpm.

Major System Consequences Becomes hard to balance these VVVV

- power
- thermal

- communications
- limited mounting space for non-scanning payloads!

Ideal inertia matrix:

increased stability.

[l_xx,0,0] [0,l_xx,0] [0,0,l_zz]

I_z to be large,
0's to ensure long term stability.
I_zz > I_xx
These conditions lead to

Choice of Spin Axis

The spin axis can only have a constant direction if it is a principal Axis.

For long-term stability it must be the axis of maximum inertia.

It may be the axis of least inertia for spin motion of limited duration.

<u>Equal inertias</u> about axes at right angles to the spin axis are needed for constant precession in response to a torque

Nutation

This is the weird shakey motion

Spinning introduces an oscillatory nutation' mode which must be damped out –

passive dampers

• active damping via control torquers

Location of masses in structure becomes really important to maintain balanced inertial matrix, limiting what can be done structurally



Spacecraft Categories - Spinner


Examples

Cluster



Astronautics - Chapter 6 - Attitude Control


Meteosat SG



Dr. H. M. Sykulska-Lawrence



Spacecraft Categories





Spacecraft Categories - Dual Spin

Part of the Structure Spinning

$$\mathbf{H} = [\mathbf{I}]\omega$$

- Upper section is despun (for example Earth pointing). Lower section (contains subsystems) spins at a rate typically 10 to 60 rpm

Major System Consequences

power

• thermal

communications

- limited mounting space
- transmission across bearing
- greater freedom of configuration

Balance

The spinning part needs to have equal inertias about axes orthogonal to the spin axis

Nutation still occurs and must be damped by the ACS

Note that methods 1 and 2 have "large" I and "small" ω in the product I ω



Spacecraft Categories - Dual Spin

Examples: Giotto







Spacecraft Categories - Dual Spin

Examples:

Intelsat 6



Galileo (Jupiter)




Astronautics - Chapter 6 - Attitude Control

Dr. H. M. Sykulska-Lawrence



Spacecraft Categories





Spacecraft Categories - Hybrid

Bias using a momentum wheel

- A rapidly rotating wheel (a momentum wheel with a rotation rate of typically 6500 rpm) is installed within the spacecraft

Configuration

The freedom of the 3-axis stabilised spacecraft, but with the interior installation of a momentum wheel (or array of momentum wheels)

Nutation

... still occurs and must be stabilised by the ACS

Momentum Storage

The wheel provides momentum storage for one component of momentum, accommodating fluctuations of about \pm 10% of the bias





Spacecraft Categories - Hybrid

Examples:


Navstar GPS



Eurostar 3000



Spacecraft Categories





Spacecraft Categories – 3 axis

No momentum bias


- The spacecraft has no significant rotating components (and therefore has effectively zero angular momentum)

Used when full motion around all axes is required for the mission

Example:

Hubble Space Telescope






Astronautics - Chapter 6 - Attitude Control

Dr. H. M. Sykulska-Lawrence



Spacecraft Categories – 3 axis

Example: Envisat 1




Astronautics - Chapter 6 - Attitude Control

Dr. H. M. Sykulska-Lawrence



Spacecraft Categories – 3 axis

Example: Magellan VOIR mission (Venus Radar mapper)






Typical ACS operation showing flow of information:

Services required:

- power,
- propulsion,
- on-board data handling,
 - communications,

etc.





Categories of Torques:

External:


Due to interactions with the environment

changes the overall angular momentum of the system

Internal:

 Due to interactions between two parts of the spacecraft

overall angular momentum of the system is conserved





External torques and torquers

A. Naturally occuring (disturbance) torques

Aerodynamic< 500 km

Gravity gradient30,000 to


40,000 km

Solar radiation all heights

- Magnetic < 30,000 to 40,000 km

Thrust misalignment all heights

Note that: the altitude ranges given are very approximate




Southampton Southampton

Torques and Torquers

External torques and torquers

- B. Controllable external torquers
 - Gas jets (thrusters)
 - Suitable for any torque size
 - ON-OFF control only
 - Require propellant
 - Magnetorquers
 - No torque about field line
 - Require on-board magnetic field model
 - require power (no propellant)








External torques and torquers

- Adjustable spacecraft geometry (to utilise aerodynamic or solar radiation pressure torques)
 - Low torque capability
 - No propellant required

Note: A control torquer of type B
is a necessity, to control
the total spacecraft
angular momentum





Internal torques and torquers

 These do no affect the total angular momentum build-up of the spacecraft. They transfer momentum from one part of the spacecraft to another.

A. Internal disturbance torques

- Mechanisms (e.g. deployment of a solar array)
- Fuel movement (sometimes referred to a 'fuel slosh')
- Astronaut movement



Internal torques and torquers

- B. Controllable internal torquers
 - Dual spin mechanisms
 - Reaction wheels (commonly used for large 'slew manoeuvres')
 - Momentum wheels (used to generate momentum bias)







Demonstrations of internal torquers

Reaction wheel demo

$$I_1\omega_1 = I_2\omega_2$$

 Gimballed momentum wheel demo (sometimes referred to as a 'control moment gyro')







Use of momentum storage

These wheel devices store angular momentum, with their torque motor controlling the flow of momentum between the wheel and the spacecraft. Their function, if installed, is primary pointing control. The use of external torquers are required to prevent excessive build-up of angular momentum

Control of spacecraft pointing can be achieved avoiding the frequent use of external torquers (thrusters or magnetorquers) ...



1/2

Torques and Torquers

Use of momentum storage


Momentum storage capacity can be chosen so as to avoid the use of external torquers (fuel) for controlling repointing and other events in which the 'before' and 'after'

momenta are equal

(i.e. periodic variation in momentum)

Example: Earth-pointing from an elliptic orbit ...

The local vertical's angular rate, and therefore the spacecraft's angular momentum, varies throughout one orbit




Dr. H. M. Sykulska-Lawrence



Momentum dumping (or 'wheel desaturation')

Disturbance torques can cause the mean angular momentum of the system to increase. Pointing control then requires progressively higher wheel speeds



Initiate momentum dump once max wheel speed is attained:


- -Torque wheel to slow it down
- -While switching to external torquers for pointing control

Southampton

Attitude sensors

Categories of sensors

Note that: Attitude control is less accurate than its measurement



Reference Sensors

... which give attitude information relative to a reference source (e.g. a star)

Inertial Sensors

... which measure changes in attitude

Southampton


Attitude sensors

Categories of sensors

A. Reference sensors

- These give information about the vector direction from the spacecraft to a reference object, in the spacecraft body axes.
- Potential accuracy is limited by the characteristics of the reference object:

Note that: the accuracies given are very approximate best performances



*Depends on receiver baseline

Southampton Southampton

Attitude sensors

Categories of sensors

B. Inertial sensors

- These are gyroscopic devices which give 'change-of-attitude' information only
- They need to be calibrated regularly using reference sensors (☆)
- They will continue to function whilst a reference object is eclipsed.

(☆) Note: Spacecraft must carry sensors of Type A



Attitude sensors

Example: Space shuttle attitude sensing system


- Gyros and star trackers.





Attitude sensors

Example: AEOLUS – Combination of star mapper and IMU






On-board Processing - closing the loop

On-board verses ground:

- The amount of autonomy given to the OBC varies considerably
- In general, modal control will be done by the OBC, with monitoring, resetting commands from Ground Control

Operational modes:
Standby
Initial Acquisition Mode (IAM)/Safe
Mode (SM)
Thruster Control Mode (TCM)
Normal Mode (NM)





Impact of ACS on the spacecraft system

ACS has major interactions with other subsystems


- Major system consequences for Type 1 (pure spinner) and Type
 2 (dual-spinner)
 - <u>Power:</u> Power limited.
 - Thermal: Spin distributes solar thermal input equitably. This
 decreases thermal design complexity, but placement of radiator
 surfaces can be problematic.
 - Communications: Antenna pointing problematic. This difficulty is eased in Type 2 configurations.
 - Payload accommodation: Limited physical space for non-scanning payloads
 - Transmission across electromechanical bearing: Type 2



Impact of ACS on the spacecraft system

<u>Mass distribution:</u> The inertia matrix must take a particular form

$$\begin{bmatrix} \mathbf{I} \end{bmatrix} = \begin{pmatrix} I_{xx} & 0 & 0 \\ 0 & I_{xx} & 0 \\ 0 & 0 & I_{zz} \end{pmatrix}, \quad (I_{xx} = I_{yy})$$



Further for long-term stability, we require $I_{77} > I_{xx}$.

$$I_{zz} > I_{xx}$$
.

- <u>Nutation</u>: Spinning introduces this oscillatory mode. This must be damped out using
 - Passive dampers
 - Active damping via control torquers



Impact of ACS on the spacecraft system

Major system consequences for Type 3 (hybrid) and Type 4 (3-axis)

- Power: Deployed solar arrays may be used, providing greater power generation capability.
- <u>Thermal:</u> Significant thermal gradients can occur, increasing complexity of thermal design.
- <u>Communications and payload accommodation:</u> Greater flexibility than for Types 1 and 2.
- Mass distribution and nutation: No major constraints, although
 Type 3 (hybrid) will exhibit nutation.



ACS Conclusions

- Attitude stabilisation type + diverse attitude pointing requirements
 - Profound effect upon spacecraft configuration

- Mass distribution has an important effect on attitude motion
 - Stability
 - Response to control torques
- There are many workable alternative designs for an ACS



Chapter 6 Summary

Attitude Control Introduction >

ACS typical feedback control loop

Key points:

Subsystem

Rotational Dynamics

• Basic principles of angular momentum

• The inertia matrix and its importance to vehicle response and design

Purposes and requirements of the Attitude Control

• Gyroscopic precession and gyroscopic rigidity (momentum bias)

Momentum Management

• How the overall momentum is managed for the spacecraft

• Key principles of momentum management, the use of momentum bias and how it affects the systems response to applied torques

Spacecraft Categories

The four active types of spacecraft stabilisationThe consequences of these types on the spacecraft design

Torques and Torquers **Attitude Sensors** On-board processing

 Categorisation of torques and torquers and examples of each

• The practical use of momentum storage leading to momentum dumping

• Categorisation of sensors used in the ACS subsystem

Modes of operation

 Important impacts of the ACS subsystem on the design and operation of the spacecraft


Impact of the ACS on the Spacecraft System

Dr. H. M. Sykulska-Lawrence

Astronautics - Chapter 6 - Attitude Control



Chapter 6 Summary



Read Chapter 9 of Fortescue, Stark & Swinerd