
# SESA3029 Aerothermodynamics Lecture 3.2

Method of characteristics: theory (part B)

# Recap: Supersonic flow characteristics



Governing equations for homentropic flow reduced to

$$\mathbf{A} = \begin{pmatrix} 0 & \tan \mu \\ -\tan \mu & 0 \end{pmatrix}$$

$$\frac{\partial \mathbf{Q}}{\partial s} + \mathbf{A} \frac{\partial \mathbf{Q}}{\partial n} = 0$$

The character of the solution will be determined by the properties of **A** 

Eigenvalues of A:

$$\lambda = \pm \tan \mu$$

## Diagonalisation of A

Any (non-defective) square matrix can be written as

$$AS = S\Lambda$$

**S**=right eigenvector matrix  $AS = S\Lambda$  S-left eigenvector matrix  $\Lambda$ =diag( $\lambda_1$ ,  $\lambda_2$ )=eigenvalue matrix

$$\mathbf{A} = \begin{pmatrix} 0 & -\tan \mu \\ -\tan \mu & 0 \end{pmatrix} \qquad \mathbf{S} = \begin{pmatrix} \frac{1}{2} & \frac{1}{2} \\ -\frac{1}{2} & \frac{1}{2} \end{pmatrix} \qquad \mathbf{S}^{-1} = \begin{pmatrix} 1 & -1 \\ 1 & 1 \end{pmatrix} \qquad \Lambda = \begin{pmatrix} \tan \mu & 0 \\ 0 & -\tan \mu \end{pmatrix}$$

With 
$$\mathbf{Q} = \begin{pmatrix} v \\ \theta \end{pmatrix}$$
 we had:  $\frac{\partial \mathbf{Q}}{\partial s} + \mathbf{A} \frac{\partial \mathbf{Q}}{\partial n} = 0$  
$$\frac{\partial \mathbf{Q}}{\partial s} + \mathbf{S} \mathbf{\Lambda} \mathbf{S}^{-1} \frac{\partial \mathbf{Q}}{\partial n} = 0$$
 
$$\mathbf{S}^{-1} \frac{\partial \mathbf{Q}}{\partial s} + \mathbf{\Lambda} \mathbf{S}^{-1} \frac{\partial \mathbf{Q}}{\partial n} = 0$$


From definitions of **Q** and **S**<sup>-1</sup> we have decoupled equations:

$$\lambda_1: \frac{\partial (v-\theta)}{\partial s} + \tan \mu \frac{\partial (v-\theta)}{\partial n} = 0$$

$$\lambda_2: \frac{\partial (\nu + \theta)}{\partial s} - \tan \mu \frac{\partial (\nu + \theta)}{\partial n} = 0$$

This is just a more useful form of the version derived pre-matrixification with this form being derived from strange matix manipulation

#### Riemann invariants



Along C+, R+=v- $\theta$  is constant Along C<sup>-</sup>, R<sup>-</sup>=v+ $\theta$  is constant

First one is simple application of first order taylor series to some

Change in some property  $f = \frac{\partial f}{\partial s} \Delta s + \frac{\partial f}{\partial n} \Delta n$  function f along OP

$$\frac{\Delta f}{\Delta s} = \frac{\partial f}{\partial s} + \frac{\partial f}{\partial n} \frac{\Delta n}{\Delta s}$$

$$\frac{\Delta f}{\Delta s} = \frac{\partial f}{\partial s} + \frac{\partial f}{\partial n} \frac{\Delta n}{\Delta s}$$
Now describing property change gradient
$$\frac{\partial f}{\partial s} = \frac{\partial f}{\partial s} + \frac{\partial f}{\partial n} \frac{\Delta n}{\Delta s}$$
Now describing property change gradient

$$= \frac{\partial f}{\partial s} + \tan \mu \frac{\partial f}{\partial n}^{\text{al}}$$

Compare with previous result:

$$\lambda_1: \frac{\partial (v-\theta)}{\partial s} + \tan \mu \frac{\partial (v-\theta)}{\partial n} = 0$$

$$\lambda_2: \frac{\partial (v+\theta)}{\partial s} - \tan \mu \frac{\partial (v+\theta)}{\partial n} = 0$$
 theta is INVARIENT along a characteristic line


Consider what happens if: f = \nu-\etheta If we follow tan then the change in popertys is zero!

What this translates to is that nu-

These are called the compatibility conditions

R<sup>+</sup> and R<sup>-</sup> are called the **Riemann invariants** (N.B. R<sup>+</sup>=-K<sup>+</sup>, R<sup>-</sup>=K<sup>-</sup> from Anderson)

#### Method of characteristics



Suppose we know the flow state at points A and B

$$R_A^+ = \nu_A (M_A) - \theta_A$$

$$R_B^- = \nu_B (M_B) + \theta_B$$

At point P we must have

$$v_P - \theta_P = R_A^+$$

$$\nu_P + \theta_P = R_B^-$$


Hence, at point P

$$v_P = \frac{R_A^+ + R_B^-}{2}$$
  $\theta_P = \frac{R_B^- - R_A^+}{2}$ 

From IFT we can find M<sub>P</sub>, hence we have marched the solution downstream

if we want to know the value of alpha along these lines we need to keep in mind that the green lines curve on large scales, so it's actually more accurate to calculate the value at B and P then use the average instead of just one or the other,

# Geometry



Average angles

$$\alpha_{AP} = \frac{1}{2} \left[ \left( \theta + \mu \right)_A + \left( \theta + \mu \right)_P \right]$$

$$\alpha_{BP} = \frac{1}{2} \left[ \left( \theta - \mu \right)_B + \left( \theta - \mu \right)_P \right]$$

$$2^{\lfloor (3-\mu)_B \rfloor}$$

Geometry

$$\tan \alpha_{AP} = \frac{y_P - y_A}{x_P - x_A}$$


$$\tan \alpha_{BP} = \frac{y_P - y_B}{x_P - x_B}$$

$$(x_P - x_B)\tan \alpha_{BP} = (x_P - x_A)\tan \alpha_{AP} + y_A - y_B$$


$$x_p = \frac{x_B \tan \alpha_{BP} - x_A \tan \alpha_{AP} + y_A - y_B}{\tan \alpha_{BP} - \tan \alpha_{AP}} \quad \text{and} \quad y_P = y_A + (x_P - x_A) \tan \alpha_{AP}$$

This process of using 2 points to get the properties of a downstream point is the "unit process", it evaluates the values downstream using upstream conditions. That being said fundamentally it relys on linear approximations of curved lines, which means smaller units yield a more accurate approximation

Unit process example



## Repeat unit process to construct complete flowfield



#### Calculation method

- 1. Calculate v(M),  $\theta$  and  $\mu$  at a number of points on a starting line from known conditions (u,v,T) and hence find R<sup>+</sup> and R<sup>-</sup> for all points
- 2. Calculate the angles  $\theta + \mu$  and  $\theta \mu$  at each point.
- 3. March downstream and identify crossing points. Calculate v(M) and  $\theta$  at these points.
- 4. Calculate M (from  $\nu$ ) and hence  $\mu = \sin^{-1}(1/M)$
- 5. Find angles  $\alpha$  and hence the co-ordinates of the new points
- 6. Repeat the process moving downstream