

RX Family

R20AN0103EJ0103 Rev.1.03 Oct 01, 2016

DNS client using the embedded TCP/IP M3S-T4-Tiny Module

Firmware Integration Technology

Introduction

This application note explains DNS client using the embedded TCP/IP M3S-T4-Tiny Module (hereafter DNS client).

DNS client is provided as Firmware Integration Technology (FIT) Module. Please refer to the URL to know FIT outline.

https://www.renesas.com/en-us/solutions/rx-applications/fit.html

DNS client is used by combining the following middleware products.

Table 1 Middleware products

Function	product	website
TCP/IP	M3S-T4-Tiny	http://www.renesas.com/mw/t4
	(hereafter T4)	

We prepared sample programs for each CPU board included in the Renesas Starter Kit. For more information, see Renesas Starter Kit for sample application notes.

Table 2 Sample application notes

document number	website
R20AN0314	http://www.renesas.com/mw/t4

Target Device

RX Family

Contents

1.	Outline	3
1.1	1 System Structure	3
1.2		
2.	API Information	5
2.	1 Hardware Requirements	5
2.2		
2.3	3 Supported Toolchains	5
2.4	4 Limitations	5
2.5	5 Header Files	5
2.6	6 Configuration Overview	5
2.7	7 API DATA Structures	6
2.8	8 Adding Library to Your Project	6
3.	API Functions	7
3.	1 R_dns_resolve_name	7
3.2	2 R_dns_init	8
3.3	3 R_dns_process	9
3.4	4 R_T4_DNS_CLIENT_GetVersion	10
4.	Technical data	11

1. Outline

DNS client is the program getting IP address which corresponds to domain name (<u>www.renesas.com</u> etc.) from DNS server.

1.1 System Structure

Show System Structure Example.




Figure 1 System Structure Example

1.2 Software Structure

Show Software Structure Example.




Figure 2 Software Structure Example (in case, store the web contents to MMC/USB memory)

2. API Information

2.1 Hardware Requirements

None

2.2 Software Requirements

This module is dependent upon the following packages:

 r_t4_rx

2.3 Supported Toolchains

This library is tested and working with following toolchains: Renesas RX Toolchain v.2.04.01

2.4 Limitations

None

2.5 Header Files

All API calls are accessed by including a single file "r_t4_dns_client_rx_if.h" which is supplied with this software's project code.

2.6 Configuration Overview

All configurable options that can be set at build time are located in the file "r_t4_dns_client_rx_config.h". A summary of these settings are provided in the following table:

Table 3 Configuration options

Configuration options in r_t4_dns_client_rx_config.h			
#define DNS_IP_ADDR_1	Set the primary DNS server IP address.		
*Default value is "172,30,11,5".			
#define DNS_IP_ADDR_2	Set the secondary DNS server IP address.		
#define DNS_TIMEOUT	Set the time out which queries to DNS server.		
※Default value is "5".	Positive value : the time waiting to complete sending.		
	Unit is 10ms.		
	TMO_FEVR: wait to complete sending forever.		
	TMO_NBLK: non-blocking call		
#define NAME_SIZE	Maximum size of domain name which queries to DNS		
※Default value is "256".	server.		
#define DNS_UDP_CEP_ID	UDP communication end point ID for DNS in file		
※Default value is "1".	'config_tcpudp.c'.		

2.7 API DATA Structures

This details the data structures of argument which used with the API function. This structure listed in the "r_t4_dns_client_rx_if.h" with API function prototypes.

```
[DNS data structure]

typedef struct _name_table
{
    char name[NAME_SIZE];
    unsigned char ipaddr[4];
}NAME TABLE;
```

2.8 Adding Library to Your Project

Please refer to the Adding Firmware Integration Technology Modules to Projects (r01an1723eu0111_rx.pdf, for e² studio) or the Adding Firmware Integration Technology Modules to CS+ Projects (r01an1826ej0102_rx.pdf).

3. API Functions

3.1 R_dns_resolve_name

This function sets the domain name which queries to DNS server.

Format

Parameters

```
name input pointer to domain name string to resolve func input pointer to callback function which is called when query to DNS server is finished.
```

Return Value

```
E_OK normal terminations
E_DNS_PROCESSING processing
Other abnormal terminations
```

Properties

Prototyped in file "r_t4_dns_client_rx_if.h".

Description

The application calls this function after calling tcpudp_open(). This function is set the domain name (www.renesas.com etc.) query to DNS server in first argument. At the end of the query, callback function would be called that is specified in second argument, user can get DNS server response. If this function is called during the query to DNS server, returns E_DNS_PROCESSING.

Reentrant

No

Special Notes

None

3.2 R_dns_init

This function initializes the management information of DNS client.

Format

void R_dns_init (void)

Parameters

None

Return Value

None

Properties

Prototyped in file "r_t4_dns_client_rx_if.h".

Description

The application calls this function only once before calling $R_dns_resolve_name()$ in initial sequence. This function initializes the management information of DNS client.

Reentrant

Yes

Special Notes

None

3.3 R_dns_process

This function is periodic process of DNS client.

Format

```
int32_t R_dns_process(void)
```

Parameters

None

Return Value

E_OK Normal terminations
E_DNS_INTERNAL Internal error

E_DNS_TIMEOUT Time out query to DNS server

Other Abnormal terminations except for the above

Properties

Prototyped in file "r_t4_dns_client_rx_if.h".

Description

Application must call this function periodically after calling tcpudp_open().

After set the domain name query to DNS server in R_dns_resolve_name(), the process of DNS client is executed in this function. When the process of DNS client is normal terminations or abnormal terminations, called callback function set in R_dns_resolve_name(). If no response from DNS server when the time set DNS_TIMEOUT macro in "r_t4_dns_client_rx_if.h" is passed, after retry the prevision times, returns E_DNS_TIMEOUT.

Reentrant

No.

Special Notes

None

3.4 R_T4_DNS_CLIENT_GetVersion

This function returns the version number of DNS client.

Format

Parameters

None

Return Value

Version number of DNS Client

Properties

Prototyped in file "r_t4_dns_client_rx_if.h".

Description

Returns the version of this module. The version number is encoded such that the top two bytes are the major version number and the bottom two bytes are the minor version number.

For example, version '4.25', the return value is '0x00040019'.

Reentrant

Yes

Special Notes

This function is inlined using the "#pragma inline" directive in "r_dns_client.c".

4. Technical data

DNS RFC URL

 $\underline{http://ftp.rfc\text{-}editor.org/in\text{-}notes/rfc1034.txt}$

 $\underline{http://ftp.rfc\text{-}editor.org/in\text{-}notes/rfc1035.txt}$

Website and Support

Renesas Electronics Website http://www.renesas.com/

Inquiries

http://www.renesas.com/contact/

All trademarks and registered trademarks are the property of their respective owners.

Revision History

Description

Rev.	Date	Page	Summary
1.03	Oct.01.16		Updated the xml file for FIT.
1.02	Jul.01.14	1	Fixed Fit Module's Web page URL
			Added Support MCUs
		4	Fixed Figure 2
1.01	May.09.14		Corresponded to FIT Modules.
1.00	Apr.04.11		First edition issued

General Precautions in the Handling of Microprocessing Unit and Microcontroller Unit Products

The following usage notes are applicable to all Microprocessing unit and Microcontroller unit products from Renesas. For detailed usage notes on the products covered by this document, refer to the relevant sections of the document as well as any technical updates that have been issued for the products.

1. Handling of Unused Pins

Handle unused pins in accordance with the directions given under Handling of Unused Pins in the manual.

The input pins of CMOS products are generally in the high-impedance state. In operation with an unused pin in the open-circuit state, extra electromagnetic noise is induced in the vicinity of LSI, an associated shoot-through current flows internally, and malfunctions occur due to the false recognition of the pin state as an input signal become possible. Unused pins should be handled as described under Handling of Unused Pins in the manual.

2. Processing at Power-on

The state of the product is undefined at the moment when power is supplied.

- The states of internal circuits in the LSI are indeterminate and the states of register settings and pins are undefined at the moment when power is supplied.
 - In a finished product where the reset signal is applied to the external reset pin, the states of pins are not guaranteed from the moment when power is supplied until the reset process is completed.

In a similar way, the states of pins in a product that is reset by an on-chip power-on reset function are not guaranteed from the moment when power is supplied until the power reaches the level at which resetting has been specified.

3. Prohibition of Access to Reserved Addresses

Access to reserved addresses is prohibited.

 The reserved addresses are provided for the possible future expansion of functions. Do not access these addresses; the correct operation of LSI is not guaranteed if they are accessed.

4. Clock Signals

After applying a reset, only release the reset line after the operating clock signal has become stable. When switching the clock signal during program execution, wait until the target clock signal has stabilized.

When the clock signal is generated with an external resonator (or from an external oscillator) during a reset, ensure that the reset line is only released after full stabilization of the clock signal. Moreover, when switching to a clock signal produced with an external resonator (or by an external oscillator) while program execution is in progress, wait until the target clock signal is stable.

5. Differences between Products

Before changing from one product to another, i.e. to a product with a different part number, confirm that the change will not lead to problems.

The characteristics of Microprocessing unit or Microcontroller unit products in the same group but having a different part number may differ in terms of the internal memory capacity, layout pattern, and other factors, which can affect the ranges of electrical characteristics, such as characteristic values, operating margins, immunity to noise, and amount of radiated noise. When changing to a product with a different part number, implement a system-evaluation test for the given product.

Notice

- 1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information,
- 2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein
- 3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or
- 4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product
- 5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment: and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.

- 6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult,
- 8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
- 10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics
- 11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics



SALES OFFICES

Renesas Electronics Corporation

http://www.renesas.com

Refer to "http://www.renesas.com/" for the latest and detailed information.

Renesas Electronics America Inc. 2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A. Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited

9251 Yongo Street, Suite 8309 Richmond Hill, Ontario Canada L4C 9T3 Tel: +1-905-237-2004

Renesas Electronics Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K
Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH

Arcadiastrasse 10, 40472 Düsseldorf, Germany Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd. Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333

Renesas Electronics Hong Kong Limited
Unit 1601-1611, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022

Renesas Electronics Taiwan Co., Ltd. 13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan Tel: +886-2-8175-9600, Fax: +886 2-8175-9670

Renesas Electronics Singapore Pte. Ltd. 80 Bendemeer Road, Unit #06-02 Hyflux Ini Tel: +65-6213-0200, Fax: +65-6213-0300 Innovation Centre, Singapore 339949

Renesas Electronics Malaysia Sdn.Bhd.
Unit 1207, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics India Pvt. Ltd. No.777C, 100 Feet Road, HALII Stage, Indiranagar, Bangalore, India Tel: +91-80-67208700, Fax: +91-80-67208777

Renesas Electronics Korea Co., Ltd. 12F., 234 Teheran-ro, Gangnam-Gu, Seoul, 135-080, Korea Tel: +82-2-558-3737, Fax: +82-2-558-5141

© 2016 Renesas Electronics Corporation. All rights reserved.