

2-2-7 Bearing Lubrication

Motors using rolling bearings and double shielded bearing (bearing model suffix: ZZ) are pre-greased and do not require re-grease. The shaft must be rotated several times once a month to ensure that the grease is evenly distributed inside the bearing. If the motor has been stopped for more than three months, run the motor at a low speed first to confirm whether the bearing can operate normally, and then slowly increase the speed to the original working conditions.

2-2-8 Moving after Storage

After a long period of time of shut down or storage, before the motor is powered on, a complete winding resistance measurement and bearing assembly inspection must be performed to check for rust, bearing damage and deformation.

If the following conditions are found, make sure to properly handle the problems before putting the motor into use.

- a. The insulation resistance is lower than the regulated value.
- b. Rust or any signs of moisture gets inside the motor.
- c. The bearings are rusted, damaged, or deformed, etc.
- d. The motor is shut down or stored beyond the warranty period.
- e. The motor is shut down or stored in a dirty or harsh environment.
- f. Store the motor in areas without temperature control where the ambient temperature and humidity vary greatly.
- g. The motor is stopped or stored in an area subject to vibration, such as when there is heavy machinery or heavy traffic nearby.
- h. Store the motor outdoors.
- i. Keep written maintenance records to prove that the motor has been maintained and stored in accordance with the instructions.

If the above conditions are found, make sure to take proper treatments before putting the motor into use and contact Delta if necessary. However, the maintenance/ repair required due to the above reasons is not included in the product warranty, and the customer must bear the relevant costs for the damaged parts that need to be replaced during the maintenance/ repair process.