

3-1 Installation Environment

General standard environment of the Motor:

- The ambient temperature should $-15 - +40^{\circ}\text{C}$, the relative temperature is below 95%, and the altitude is below 1000m.
- Indoor use only, no harmful gas, liquid, without dust and foreign object, no splashing, water-soaked environment.
- Fix the motor in an environment with sufficient rigidity and without resonance or impact.
- There should be enough space around the motor for unobstructed air intake, air exhaust and maintenance. If the motor is installed in a poorly ventilated room, it is easy to cause the surrounding ambient temperature to rise, affecting the heat dissipation effect of the motor.
- Do not allow foreign objects such as various fibers, pieces of paper, wood chips (chips) or metal fragments to enter the motor drive or adhere to the cooling fan.