

Table of Contents

Chapter 1 Introduction	1
1-1 Product Description	3
1-2 Nameplate Information	3
1-3 Serial Number	4
1-4 Model Name	4
1-5 Common Motor Standard	5
1-6 Motor Characteristic Curves	6
1-7 Motor Parameters	7
1-8 Motor Appearance and Dimensions	11
Chapter 2 Unpacking	29
2-1 Receiving	31
2-2 Storage	32
2-3 Transportation	35
2-4 Packaging and Weight	37
Chapter 3 Installation of Motor	41
3-1 Installation Environment	43
3-2 Installation Space	44
3-3 Installation Method	45
3-4 Wiring Precautions	51
3-5 Inspection before Wiring	52
3-6 Wiring Method	53
3-7 Motor Terminal Specification	55
Chapter 4 Motor Operation	57
4-1 Motor Pre-start Inspection	59
4-2 Adjustment and Application	60
4-3 Motor Start and Operation	74
Chapter 5 User Suggestions & After-Sales Service	77
5-1 Cleaning the Cooling Fan in the Motor Rear Hood	79
5-2 Motor Exterior Cleaning	80
5-3 Motor Failure and Analysis	81
5-4 After-sales Service Process (ASP)	83

Issued Edition: 00
Issued Date: 2025/02