

4-2-2-2 PM SVC Adjustment Procedure

(※ the number marked on the procedure corresponds to the number of following adjustment explanations)

(1) PM SVC motor parameters adjustment

