


2-3-3 Position of the Lifting Eye Bolts

Installation of B3 Model

One lifting eye bolt which is located on the same side as the junction box at the top.



Installation of V1 Model

Two lifting eye bolts

- Aluminum case: On both sides of the junction box
- Cast iron case: On the same and opposite side of the junction box

Aluminum Case (HT)	Cast Iron Case (ZL)
