


- Click **Tool Orientation Set** to calculate and write the new Tool Frame directions to the controller.



- The converted Tool Frame directions are as follows.

