



The detailed descriptions for the types of workspace are as follows.

■ Rectangle

Refer to the following figure. Create a rectangular workspace by clicking the **Teach** button in the Point operation areas each time after moving the robot to the positions PO, PX, and PY. Set the workspace as a **Working Area** or **Restricted Area** in the **Work Space** tab, and then click **Set** to write the settings to the controller.

Rectangle			
	X (mm)	Y (mm)	Z (mm)
PO	467	-85	-12
PX	475	-85	-12
▶ PY	467	-60	-60



Teaching a rectangular workspace