


- 5. Move the robot to the PY position to be set on the rectangle. Click the **PY** table row, and then click **Teach**.



4

Work Space

ID1

TypeRectangle

StatusDisable

Show Alarm☒

AreaRestricted Area

Restricted Area DO

Disable

DO1

ON

Work Space is Closed

Rectangle

	X (mm)	Y (mm)	Z (mm)
PO	467	-85	-12
PX	472	-85	-12
PY	467	-20	-60

PO

PY

PX

Reset

Get

Set

Motion Command(mm)

Please choose one point

File:Workspace

Name:

Motion:MoveP

Teach

Ext

Go

Check All☐