


1.3.1 Login permissions

To ensure the operating personnel's safety, the software only shows the main page after started. You can click  (Login permissions) to log in for the proper operation permissions.



There are three types of operation permissions. The permission passwords and accessible pages are as follows.

Operation permissions	Password	Description
Operator	0000	Operators are able to select, execute, and stop projects.
Technician	1111	Apart from the operator's permissible operations, technicians are able to develop projects, edit programs, and operate the robots.
Engineer	2222	Apart from the technician's permissible operations, engineers have full permissions and are able to adjust and set the robot parameters.

Page		Operator	Technician	Engineer
Quick access toolbar	Login permissions	✓	✓	✓
	Robot model selection	✓	✓	✓
	Connection	✓	✓	✓
	Servo control	✓	✓	✓
	TP status	✓	✓	✓