


5.2.2 Variable monitoring

When the program execution pauses at a breakpoint, go to the **RL** subpage, click the **Global** or **Local***Note subtab, enter the variables to be monitored in the Name column, and then you can check their values and types.



Global		
Name	Value	Type
sum	4	Number

Local		
Name	Value	Type
data	6	Number

Note: in the robot programming language, if you do not use the “local” keyword before the variable declaration, the variable is a global variable.