


User DI & User DO

Before a project is opened, the User DI and User DO areas are displayed as follows.



Item	Name	Description
1	Signal On / Off	1 : the DI/O is On. 1 : the DI/O is Off. Note: to switch On or Off the User DOs, you can click 1 or 1 directly, or use the RL instruction <code>DO(#,ON)</code> or <code>DO(#,OFF)</code> (# indicates the DO number).
2	DI/O name	Displays the user-defined name.

To define the DI/O name, you need to first open the corresponding project* ^{Note}.



Note: refer to Chapter 3 for details on how to open a project.