

Return to **User IO** and the fields for DI/O names are now editable with a white background. Then, you can name the DI/O signals^{*1 *2}.

6

The screenshot shows the 'User IO' configuration window. It is divided into two main sections: 'User DI' on the left and 'User DO' on the right. Each section contains a list of 19 numbered input fields (1-19 for DI, 1-12 for DO). The fields are currently empty, indicating that no names have been assigned yet.

After naming, click **User IO Save** to write the settings to the project.

This screenshot shows the 'User IO' configuration window after the signals have been named. The 'User DI' section shows the first two fields filled with 'DMV_Ready' and 'visual signal_01'. The 'User DO' section shows the first two fields filled with 'DMV_Trigger' and 'visual trigger_01'. Above the input fields, a 'User IO Save' button, represented by a blue floppy disk icon, is highlighted with a red rectangle.

Note:

- *1. The user-defined DI/O names are only displayed in the DRASstudio; it is recommended that you select plain and straightforward names.
- *2. It is suggested that you use English letters and numbers for naming the DI/Os. Garbled text may be displayed if you use the language that is not supported by the operating system.