




Home posture of 4-axis SCARA robots (with DRS60L as an example)	Home posture of 6-axis VA robots (with DRV70L as an example)
	

7

7.2 Z index

The **Z index** tab displays the mechanical home position of each robot axis in units of PUU^{*Note}. If the home position is lost due to low robot battery, refer to the values in this tab to restore the home position. Click **Get Value** to obtain the value; contact Delta if the value is 0.



Note: PUU (Pulse of User Unit) is a unit scaled by the E-Gear ratio.