


There are five drop-down list boxes in the window for selecting the robot model.



Item	Drop-down list box	Description
1	Series	Robot series
2	Arm length	Arm length of the robot
3	Type	Robot type
4	Payload	Maximum payload of the robot
5	DOF	Degree of freedom of the robot

■ Automatic model selection

Select the check box for **Function enable when connected** to enable the Automatic model selection function. After the function is enabled, the drop-down list boxes are grayed out.

