

10.4 Backup

- 1. Enter a name in the Backup Folder Name field first (only English letters and numbers can be used for naming the folder). If necessary, you can add any descriptions in the Notes field. The Backup Path is the DROEbackup folder under the installation folder.

<< Delta Industrial Automation > DELTA_IA-Robot_DRASudio-V1-00-07-41_SW_TSE_20210428 > DROEbackup			
Name	Date modified	Type	Size
test_20210618152451	6/18/2021 1:27 PM	File folder	
test_20210624152902	6/24/2021 1:50 PM	File folder	

- 2. To back up all the robot data to the PC, click **Complete Backup**^{Note}. To back up part of the data, select the check box(es) for the specific item(s), and then click **Option Backup**.

Note: the Recovery function described in Section 10.5 is available only when you back up data with the Complete Backup function.

- 3. After the backup is complete, the Status column of the table shows “Done”.

Backup

Create Backup from Controller

Backup Folder Name : test

Backup Path : C:\Delta Industrial Automation\DELTA_IA-Robot_DRASudio-V1-00-07-55_SW_20230221\DROEbackup

Notes :

Complete Backup

Option Backup

Status : Done

Check	Item	Status
☐	Controller Parameter	Done
☐	Alarm History	Done
☐	Controller Log	Done
☐	DRASudio Log	Done
☐	Device Latch	Done
☐	Compensation Data	Done
☐	Payload Parameter	Done
☐	Collision Detect Parameter	Done
☐	About Data	Done

PS : Please make sure connecting with controller. Otherwise, backup process may not be completed !

Important: make sure the robot connection is stable during backup, or the backup may fail.