

11.2 Registration

You need to first obtain the AuthorityKey(s) in the **Registration** tab before using the function(s) in the **DCS/DCV** tab.

Important: connect the PC to the Internet when you register in the **Registration** tab.

11

Menu <<

License

Registration

Registrtrtion

StickSN:

StickCode:

Company:

Department:

UserName:

PC-Name: TWTC2NB1126

PC-UUID: AD63CC002324CE8667D1F46997E5C819

RobotSN: DRS40L3SS1BN002

RobotMAC: 000400000004

Message:

AuthorityKey:

Name	Description
StickSN	Serial numbers for function registration; refer to the sticker on the USB drive. Note: the StickSN and StickCode are for one controller only. After registration, you cannot register them to other controllers.
StickCode	
Company	Information used for the after-sales service. Properly fill in the information to ensure the quality of service; for example: Company: Delta Department: Robot Automation Business UserName: Delta Engineer
Department	
UserName	
PC-Name	Click Read on the right side to obtain the information of each item. When registering the functions for multiple controllers, you need to re-enter the content of the four fields every time DRASudio connects to a new controller. Note: refer to the nameplate of the robot (marked with a red box as follows) and manually enter the serial number to the RobotSN field.
PC-UUID	
RobotSN ^{*Note} (robot serial number)	Delta Electronics, Inc. SCARA ROBOT MODEL : DRS40L3SSAD6002 S/N DRS40L3SSAT186XXXXX Document No. : DRS-CE-01 Arm Length : 400mm/15.75inch Robot Arm Weight : 17kg/37.5lb Controller Weight : 20kg/44.1lb Max.Payload : 3kg/6.6lb Rated Power : 3kW Power Supply : 220V~+PE 50/60Hz Rated Current : 10A Short-Circuit Rating : 10kA Pneumatic Pressure : Max. 0.6MPa/87psi CE SCARA ROBOT MODEL: DRS40L3SS1BN002 ARM LENGTH: 400MM WEIGHT: 16KG MAX PAYLOAD: 3KG AIR PRESSURE: MAX 0.59MPA DRS40L3SS1BN000W15360001 DELTA ELECTRONICS, INC. MADE IN CHINA
RobotMAC	
Register	After filling in the preceding fields, click this button to generate the AuthorityKey.
Message	Displays if the AuthorityKey generation is SUCCESS (successful) or FAIL (failed).
AuthorityKey	License code.