

- JRC4 indicates the JRC (Joint Rotation Count) of the J4 axis.
When $-180^{\circ} \leq \text{rotation angle} < +180^{\circ}$, the JRC4 shows 0.
When $180^{\circ} \leq \text{rotation angle} < 360^{\circ}$ or $-360^{\circ} \leq \text{rotation angle} < -180^{\circ}$, the JRC4 shows 1.
- JRC6 indicates the JRC (Joint Rotation Count) of the J6 axis.
When $-180^{\circ} \leq \text{rotation angle} < +180^{\circ}$, the JRC6 shows 0.
When $180^{\circ} \leq \text{rotation angle} < 360^{\circ}$ or $-360^{\circ} \leq \text{rotation angle} < -180^{\circ}$, the JRC6 shows 1.

JRC6: 0 -180° ≤ J6 rotation angle < +180°	JRC6: 1 180° ≤ J6 rotation angle < 360° or -360° ≤ J6 rotation angle < -180°
	