


Change Path


All projects are stored in the project folders; the default location is the [DROEsolution] folder under the installation folder, and can be changed to any location.



Item	Description
Solution Path	The current path of the project folder.
Default Path	Reset the current path of the project folder back to the default.
Change Path	Change the path of the project folder.
Apply	Apply the change.
Cancel	Cancel.

Open folder

Opens the current location of the project folder; the default location is the [DROEsolution] folder under the installation folder.



Solution Info.

Displays the currently set name and path of the project folder.

