


DIP Switch

The DIP switch sets how fast the fan speed is in different ranges of ambient temperatures. Please see the table below for setup information.



SETUP

DIP Switch	Function	Illustration
DIP ❶	To set up the range of ambient temperature: 1. Turn Off: Set the range of ambient temperature between 20°C~25°C. 2. Turn On: Set the range of ambient temperature between 20°C~27°C.	•Turn OFF:
DIP ❷	To set up fan speed: 1. Turn Off: Set fan speed to vary according to the ambient temperature. 2. Turn On: Set fan speed to the maximum.	•Turn ON: