



Table of Contents

Chapter 1: Important Safety Instructions -----1

 Safety Warnings ----- 1

 Usage Warnings ----- 1

 Standard Compliance ----- 2

Chapter 2: Introduction -----3

 General Overview ----- 3

 Features ----- 3

 Package Contents ----- 3

 Optional Accessory ----- 4

 Front Panel ----- 4

Chapter 3: Installation & Start-up-----6

Chapter 4: Interface Function ----- 11

 SOURCE & AMB. TEMP PROBE Ports ----- 11

 Dry Contact -----14

 DIP Switch -----15

Chapter 5: Maintenance ----- 16

Chapter 6: Troubleshooting ----- 17

Chapter 7: Specifications ----- 19

Chapter 8: Warranty -----20