

- The ADU is only applicable to a 600mm × 600mm raised floor with FAR *1 larger than 50%.
- If the ADU needs to be stored, keep it in an environment at a temperature between -20°C~60°C with relative humidity between 0%~90% (non-condensing).
- Before usage, you **must** allow the ADU to adjust to room temperature for at least two hours to avoid moisture condensing inside the ADU.

Standard Compliance

- CE
- EN55022 Class A

*1: FAR=Free Area Ratio; the ratio of the opening size to the total size of a raised floor.