

No.	Item	Description	Default
[c]	Syslog Server 1	The Host Name of remote Syslog Server 1.	
[d]	Syslog Server 2	The Host Name of remote Syslog Server 2.	
[e]	Syslog Server 3	The Host Name of remote Syslog Server 3.	
[f]	Syslog Server 4	The Host Name of remote Syslog Server 4.	
[g]	SNMP Get, Set Port	The SNMP port.	161



Time Server

You can manually adjust time and date for the Mini SNMP or set up automatic synchronization with the time server. The Mini SNMP and Windows support SNTP (Simple Network Time Protocol). If you need to start up a time server service on your workstation, please refer to **Chapter 7: Troubleshooting Q1**.

```
*****
|      Time Server      |
|*****|
[1]. Time Selection:      Manual
[2]. Time Zone:          +0:00
[3]. 1st Time Server:    POOL.NTP.ORG
[4]. 2nd Time Server:
[5]. Period:             0:06:00
[6]. Manual Date:        2017/08/04
[7]. Manual Time:        13:13:07
[0]. Back To Previous Menu

Mini>
```

No.	Item	Description	Default
[1]	Time Selection	SNTP or Manual.	SNTP
[2]	Time Zone	Change to your time zone.	+0 hr
[3]	1 st Time Server	The first time server for SNTP.	POOL.NTP.ORG
[4]	2 nd Time Server	The second time server for SNTP.	
[5]	Period	Auto update interval of time server.	0:06:00
[6]	Manual Date	Set the date manually.	01/01/2000
[7]	Manual Time	Set the time manually.	00:00:00