

● IPv6

This allows Administrator to configure the IPv6 parameters for the Mini SNMP.



- **DHCPv6**

Enable/ Disable DHCPv6 client. If enabled, DHCPv6 server will automatically assign an IPv6 address to the Mini SNMP.

- **IP Address**

The IPv6 address for your Mini SNMP.

- **Prefix**

The prefix length for the IPv6 address.

- **Gateway IP**

The IPv6 address for network gateway.

- **DNS 1**

The IPv6 address for Domain Name Server 1.

- **DNS 2**

The IPv6 address for Domain Name Server 2.

- **Search Domain**

If the Host Name you provided cannot be found, the system will append the search domain to your Host Name.