

SNMP Trap

The Mini SNMP provides SNMP Trap and INFORM functions. INFORM allows the Mini SNMP to send an inform request to the SNMP managers when an event is triggered. Users can set SNMP Trap to receive alert notifications when abnormalities occur. To enable SNMP Trap, add Target IP addresses to the SNMP Trap Target List, specify Community String, Trap Type, MIB, SNMPv3 User Name, Port, Event Level and then click Add. If you wish to update or delete a Target IP address, select the Target IP address in the list and click Update or Delete. The maximum number of the Target IP addresses is 32.

The screenshot shows the 'InsightPower G3 Mini SNMP Card' web interface. The 'SYSTEM' tab is selected, and the 'SNMP Trap' configuration page is displayed. The page includes a sidebar menu with options like 'Monitor', 'Device', and 'System'. The main content area shows the 'SNMP Trap' configuration section with fields for 'Trap Type', 'Trap ID', and a list of 'Target IP' addresses. A table at the bottom displays the current configuration for a single target IP.

IP	Community String	Type	Port	MIB	SNMPv3 User	Level
10.100.1.100	public	SNMPv3	162	SNMPv3	Information	



NOTE :

The Mini SNMP supports SNMPv1, SNMPv2c, SNMPv3 and INFORM traps to meet the needs of most users. If you select SNMPv3 trap, please specify an SNMPv3 USM User Name. You can choose an Event Level to determine what notification should be sent to which Target IP address. Go to **Device** → **Management** → **Event Level** for event level settings. Four event levels are as follows:

- **None:** No event notifications are sent to the Target IP address.
- **Information:** All event notifications are sent to the Target IP address.
- **Warning:** Both Warning and Alarm event notifications are sent to the Target IP address.
- **Alarm:** Only Alarm event notifications are sent to the Target IP address.
- **ShutdownAgent 2012:** performs graceful, unattended operating system shutdown. For details, please refer to the official website.