

For the definition of Input Wet Contact Signals interface, please refer to Table 2-3.

Table 2-3: The Definition of Input Wet Contact Signals Interface

Item	Pin No	Signal	Electrical Character		Function
INPUT (Wet Contacts)	1	NTC-A	NA	NA	Cabinet's ambient NTC
	2	NTC-B	NA	NA	
	3	EPO-2	24V	10 mA	System EPO (Close, Enable Open, Disable)
	4	EPO-1	24V	10 mA	
	5	SPD-A	24V	10 mA	System SPD (Close, SPD Fault Open, NO Fault)
	6	SPD-B	24V	10 mA	
	7	ON/OFF-A	24V	10 mA	PM Turn ON/OFF (Close, Turn ON Open, Turn OFF)
	8	ON/OFF-B	24V	10 mA	
	9	NC			NC



NOTE:

For NTC signal, standard NTC sensor is configured to detect cabinet temperature, please consult Delta or Delta distributor for detail application.

For the definition of RS485 interface, please refer to **Table 2-4**.

Table 2-4: The Definition of RS485 Interface

Item	Pin No	Signal	Function
RS485	1	Reserved	Internal using
	2	Reserved	
	3	Reserved	
	4	FG1	RS485 signal ground
	5	Reserved	Internal using
	6	Reserved	
	7	RS485A	Outer RS485 using
	8	RS485B	