

Item	Description
10	Shows the operating status of the device, status including operating, standby and locked.
11	Power module quantity: The number of power module that builds a connection with the HMI.
12	Displays the device wiring type, including 3P3W and 3P4W.
13	Displays the device type, including compensator and harmonic source.
14	The load icon. Click to display detailed information regarding load measurement.
15	The ON/ OFF button. Click the button to turn on/ off the button.
16	The compensator icon. Click to display detailed information regarding compensator measurement.
17	The grid icon. Click to display detailed information regarding grid measurement.
18	Page name.