


5.2 Description of the 10” HMI Display



(Figure 5-3: PQC-HMI-F10 Screen)

Item	Description
1	The "Home" button. Click to go back to the home page.
2	The "Measurement" button. Click to go to the measurement page of the next level.
3	The "Setup" button. Click to go to the setup page of the next level.
4	The "Maintenance" button. Click to go to the maintenance page of the next level.
5	Displays the current CT location. It may be on the grid's side or the load's side.
6	The "Login" button. Click to login.
7	The "Event Log" button. Click to show all errors that occur on the device.
8	The ON/ OFF button. Click the button to turn on/ off the button.
9	Displays the time and date on the device.