

- The operating environment temperature of SVG shall be between -10°C (14°F) and 55°C (131°F). The relative humidity shall be within 95% (non-condensing). For detailed derating information, please refer to **2.3 Functions & Features**.
- The SVG system shall be installed at a place with altitude less or equal to 1000 m (3280 ft). Derating 1% per 100 m (328 ft) when the altitude is between 1000 m and 3000 m (3280 ft ~ 9842 ft). For more question, please consult Delta or Delta distributor.
- Before applying electric power to the SVG, you must allow the SVG to adjust to room temperature (20°C ~ 25°C (68°F ~ 77°F)) for at least one hour and ensure that there is no moisture condensing inside the unit.
- Do not put beverages on the SVG or any other accessory associated with the SVG.
- Do not open or remove the covers or panels of the SVG to avoid high-voltage electric shock. Only authorized Delta engineers or service personnel can do so for installation or maintenance. If you want to open or remove the covers or panels, do it only under the supervision of authorized Delta engineers or service personnel.
- Some components like fans will become worn-out due to long-term usage, and this will increase the risk of SVG failure. To replace and maintain the components, please contact Delta service personnel.
- The SVG complies with the regulations of Overvoltage Category III in IEC 62477. It is suggested that appropriate surge voltage protection devices shall be chosen in accordance with the actual power system type. If appropriate protection devices are not used, the surge voltage may exceed the SVG's capacity and cause SVG damage. If you are uncertain regarding the SVG's application, please contact Delta service personnel.

Wiring System	Recommended Model	Main Technology Indicator
3P3W	Sichuan Zhongguang Lightning ZGG40-385 (3+0) Ar	Nominal Operating Voltage U_o : 230V AC Max. Continuous Operating Voltage U_c : 385V AC
3P4W	Sichuan Zhongguang Lightning ZGG40-385 (3+1) r	Rated Discharge Current I_n : 20 kA Max. Discharge Current I_{max} : 40 kA Voltage Protection Level U_p : 1.8 kV

- You must contact Delta customer service if any of the following events occurs:
 1. Any liquid is poured or splashed on the SVG.
 2. The SVG is deformed.
 3. Any conductive powders or metals enter into the SVG.
 4. The SVG does not run normally after you carefully followed the instructions in this **User Manual**.