

1.4 Storage Warnings

- Use the original packing materials to pack the SVG to prevent any possible damage from rodents.
- If the SVG needs to be stored prior to installation, it shall be placed in a dry indoor area. The allowable storage temperature is $-40^{\circ}\text{C} \sim 70^{\circ}\text{C}$ ($-40^{\circ}\text{F} \sim 158^{\circ}\text{F}$) and the relative humidity is within 95% (non-condensing).
- If the HMI needs to be stored prior to installation, it shall be placed in a dry indoor area. The allowable storage temperature is $-30^{\circ}\text{C} \sim 70^{\circ}\text{C}$ ($-22^{\circ}\text{F} \sim 158^{\circ}\text{F}$) and the relative humidity is within 95% (non-condensing).

1.5 Standard Compliance

- IEC 62477-1:2016 Safety requirements for power electronic converter systems and equipment, Part 1: General
- IEC 61000-6-2:2016 Electromagnetic compatibility (EMC) Part 6-2: Generic standards - Immunity standard for industrial environments
- IEC 61000-6-4:2018 Electromagnetic compatibility (EMC) Part 6-4: Generic standards - Emission standard for industrial environments