


4


Method for teaching the tool size

Select a fixed reference point. Move the tooltip to the reference point, and then teach at least three points with different postures to generate the tool size. Refer to the following figures.

When teaching, make sure to move the rotating axis in all directions. Move the RZ axis for the 4-axis SCARA robots; move the RY and RZ axes for the 5-axis SCARA robots; and move the RX, RY, and RZ axes for the 6-axis VA robots.



Teaching the tool size for SCARA robots



Teaching the tool size for VA robots