

5.2 Program editing

In the Editor area of the **RL** page, you can write codes for robot motion planning, I/O configuration, logical operations, and system handshake.

5.2.1 Debugging

Click the blank area to the right of the program line number, and then the  (Breakpoint) icon appears. When the breakpoints are set, the program execution pauses at the line with a breakpoint. In this scenario, click  **Step** to execute the program line by line starting from the line with a breakpoint, which helps you to find logic errors in the program. Clicking  **DeleteBKP** can delete all breakpoints.

