


Connect to Delta's industrial automation products through Delta's DMCNET system in the  **External** page in the menu of DRASstudio. This page provides visualized operations of the external DI/O and the external axis, expanding the external devices as needed for system setup and various applications.

13.1 External DI/O

This section provides descriptions of operating the external DI/O through the **External** and **RL** pages. The external DI/O devices expand the number of DI/O signals for you to control. For example, you can select the following devices (2) and (3).



(1)	(2)	(3)
Controller	External DI module	External DO module
Delta DCS / DCV robot controller	ASD-DMC-RM32MN	ASD-DMC-RM32NT