


1.3.7 Alarm

When an alarm or warning occurs, click  (Alarm) to quickly check for the robot status and the alarm or warning message.



Icon	Status	Description
	Normal	When there is no error, the icon is grayed out and not clickable.
	Alarm	When an alarm occurs, the icon flashes red. Clicking this icon can display the alarm message. To reset the alarm, click the Alarm button or the  (Reset) button in the quick access toolbar.
	Warning	When a warning occurs, the icon flashes yellow. Clicking this icon can display the warning message. However, clicking the Alarm button or  (Reset) button in the quick access toolbar cannot reset the alarm. You need to refer to the warning message for troubleshooting.

1.3.8 Reset (alarm reset)

When an alarm occurs, click  (Reset) to quickly reset the alarm. When the TP is in control of the operation, you can only reset the alarm on the TP but not through DRASudio when an alarm occurs.

Icon	Description
	No alarm occurs.
	Alarm occurs. Click to reset.