

Other precautions

Syntax

Item	Description
Case sensitivity	The robot programming language is case-sensitive. <i>a</i> and <i>A</i> are distinguishable from each other.
Separator	Program elements in the robot programming language can be separated with commas (",") or spaces. For example, "a1=0 a2=1 a3=2" is equivalent to "a1, a2, a3 = 0, 1, 2".
When variable count is greater than value count	nil is assigned to the empty variable. For example, in the statement of "a1, a2, a3 = 0, 1", the value of <i>a3</i> is nil.
When variable count is smaller than value count	The redundant value is ignored. For example, in the statement of "a1, a2 = 0, 1, 2", the value 2 is ignored.

Variable declaration

In the robot programming language, if you do not use the "local" keyword before the variable declaration, the variable is a global variable. See the following example.

a=1	-- Set <i>a</i> as a global variable
if a == 1 then	
local b = 2	-- Set <i>b</i> as a local variable
end	
if b == 2 then	-- The value of <i>b</i> is nil here, so this statement is not executed.
c = 1	
end	

Reserved keywords

The keywords in Delta's robot programming language is case-sensitive. For instance, *and* is distinguishable from *AND*.

Pay special attention when naming the variables. The following keywords cannot be used to declare the variable names.

and	global	or	until
boolean	goto	P	while
break	if	p	All the instruction names
do	in	repeat	
else	local	return	
elseif	nil	string	
end	not	table	
false	number	then	
for	OFF	thread	
function	ON	true	